

# Contents

	Page
Acknowledgements	2
About this manual	2
Introduction to the Honda 50, 70 and 90 models	5
General machine specifications	5
Ordering spare parts	5
Safety first!	6
Routine maintenance	7
Recommended lubricants	14
Working conditions and tools	14
Chapter 1 Engine and gearbox	15
Chapter 2 Clutch	61
Chapter 3 Fuel system and lubrication	67
Chapter 4 Ignition system	79
Chapter 5 Frame and forks	87
Chapter 6 Wheels, brakes and tyres	88
Chapter 7 Electrical system	109
Chapter 8 The 1977 on models	120
Wiring diagrams	115, 160
Conversion factors	166
English/American terminology	167
Index	168

## Introduction to the Honda 50,70 and 90 models

During February 1967 Honda, already well known for their step-through scooter style machine, introduced into the UK their overhead camshaft engine version of the 50 cc motor-cycle.

This technical advancement with such a small engine had the result of increasing the performance of the machine to what seemed an incredible level for such a small engine.

Later, in September of the same year, a 90 cc step through model was introduced into the UK for the rider who needed a small reserve of power whilst retaining the same degree of rider protection.

As part of Honda's rationalisation programme the 70 cc step through model was introduced in February 1972, to replace both the 50 cc model and the 90 cc model, being an intermediate size to combine the most desirable features of both machines. Public demand for all three models was such, however, that the 50 cc and 90 cc models were not discontinued and are still currently available. Recently, introduction of 'moped legislation' has caused a decline in the sales of the 50 cc model but further legislation due shortly, may turn the tide of fortune.

## General machine specifications

Model	C50	C70	C90
Overall length	1795 mm (70.67 in)	1795 mm (70.67 in)	1830 mm (72.10 in)
Overall width	640 mm (25.19 in)	640 mm (25.19 in)	640 mm (25.19 in)
Overall height	975 mm (38.4 in)	975 mm (38.4 in)	995 mm (39.2 in)
Wheelbase	1185 mm (46.65 in)	1185 mm (46.65 in)	1190 mm (46.89 in)
Ground clearance	130 mm (5.12 in)	130 mm (5.12 in)	130 mm (5.12 in)
Dry weight	68 kg (152 lb)	72 kg (159 lb)	85 kg (187 lb)

## Ordering spare parts

When ordering spare parts for any of the Honda C50, C70 or C90 models, it is advisable to deal direct with an official Honda agent, who should be able to supply most items ex-stock. Parts cannot be obtained from Honda (UK) Limited direct; all orders must be routed via an approved agent, even if the parts required are not held in stock.

Always quote the engine and frame numbers in full, particularly if parts are required for any of the earlier models. The frame number is stamped on the left-hand side of the frame, close to the top mounting point of the engine unit. The engine number is stamped on the left-hand crankcase, immediately below the flywheel generator cover.

Use only parts of genuine Honda manufacture. Pattern parts are available, some of which originate from Japan and are packaged to resemble the originals. In many instances these parts will have an adverse effect on performance and/or reliability.

Some of the more expendable parts such as spark plugs, bulbs, tyres, oils and greases etc., can be obtained from accessory shops and motor factors, who have convenient opening hours, charge lower prices and can often be found not far from home. It is also possible to obtain parts on a Mail Order basis from a number of specialists who advertise regularly in the motor cycle magazines.



Frame number location



Engine number location

# Safety first!

Professional motor mechanics are trained in safe working procedures. However enthusiastic you may be about getting on with the job in hand, do take the time to ensure that your safety is not put at risk. A moment's lack of attention can result in an accident, as can failure to observe certain elementary precautions.

There will always be new ways of having accidents, and the following points do not pretend to be a comprehensive list of all dangers; they are intended rather to make you aware of the risks and to encourage a safety-conscious approach to all work you carry out on your vehicle.

## Essential DOs and DON'Ts

**DON'T** start the engine without first ascertaining that the transmission is in neutral.

**DON'T** suddenly remove the filler cap from a hot cooling system – cover it with a cloth and release the pressure gradually first, or you may get scalded by escaping coolant.

**DON'T** attempt to drain oil until you are sure it has cooled sufficiently to avoid scalding you.

**DON'T** grasp any part of the engine, exhaust or silencer without first ascertaining that it is sufficiently cool to avoid burning you.

**DON'T** allow brake fluid or antifreeze to contact the machine's paintwork or plastic components.

**DON'T** syphon toxic liquids such as fuel, brake fluid or antifreeze by mouth, or allow them to remain on your skin.

**DON'T** inhale dust – it may be injurious to health (see *Asbestos* heading).

**DON'T** allow any spilt oil or grease to remain on the floor – wipe it up straight away, before someone slips on it.

**DON'T** use ill-fitting spanners or other tools which may slip and cause injury.

**DON'T** attempt to lift a heavy component which may be beyond your capability – get assistance.

**DON'T** rush to finish a job, or take unverified short cuts.

**DON'T** allow children or animals in or around an unattended vehicle.

**DON'T** inflate a tyre to a pressure above the recommended maximum. Apart from overstressing the carcass and wheel rim, in extreme cases the tyre may blow off forcibly.

**DO** ensure that the machine is supported securely at all times. This is especially important when the machine is blocked up to aid wheel or fork removal.

**DO** take care when attempting to slacken a stubborn nut or bolt. It is generally better to pull on a spanner, rather than push, so that if slippage occurs you fall away from the machine rather than on to it.

**DO** wear eye protection when using power tools such as drill, sander, bench grinder etc.

**DO** use a barrier cream on your hands prior to undertaking dirty jobs – it will protect your skin from infection as well as making the dirt easier to remove afterwards; but make sure your hands aren't left slippery. Note that long-term contact with used engine oil can be a health hazard.

**DO** keep loose clothing (cuffs, tie etc) and long hair well out of the way of moving mechanical parts.

**DO** remove rings, wristwatch etc, before working on the vehicle – especially the electrical system.

**DO** keep your work area tidy – it is only too easy to fall over articles left lying around.

**DO** exercise caution when compressing springs for removal or installation. Ensure that the tension is applied and released in a controlled manner, using suitable tools which preclude the possibility of the spring escaping violently.

**DO** ensure that any lifting tackle used has a safe working load rating adequate for the job.

**DO** get someone to check periodically that all is well, when working alone on the vehicle.

**DO** carry out work in a logical sequence and check that everything is correctly assembled and tightened afterwards.

**DO** remember that your vehicle's safety affects that of yourself and others. If in doubt on any point, get specialist advice.

**IF**, in spite of following these precautions, you are unfortunate enough to injure yourself, seek medical attention as soon as possible.

## Asbestos

Certain friction, insulating, sealing, and other products – such as brake linings, clutch linings, gaskets, etc – contain asbestos. *Extreme care must be taken to avoid inhalation of dust from such products since it is hazardous to health.* If in doubt, assume that they do contain asbestos.

## Fire

Remember at all times that petrol (gasoline) is highly flammable. Never smoke, or have any kind of naked flame around, when working on the vehicle. But the risk does not end there – a spark caused by an electrical short-circuit, by two metal surfaces contacting each other, by careless use of tools, or even by static electricity built up in your body under certain conditions, can ignite petrol vapour, which in a confined space is highly explosive.

Always disconnect the battery earth (ground) terminal before working on any part of the fuel or electrical system, and never risk spilling fuel on to a hot engine or exhaust.

It is recommended that a fire extinguisher of a type suitable for fuel and electrical fires is kept handy in the garage or workplace at all times. Never try to extinguish a fuel or electrical fire with water.

**Note:** Any reference to a 'torch' appearing in this manual should always be taken to mean a hand-held battery-operated electric lamp or flashlight. It does not mean a welding/gas torch or blowlamp.

## Fumes

Certain fumes are highly toxic and can quickly cause unconsciousness and even death if inhaled to any extent. Petrol (gasoline) vapour comes into this category, as do the vapours from certain solvents such as trichloroethylene. Any draining or pouring of such volatile fluids should be done in a well ventilated area.

When using cleaning fluids and solvents, read the instructions carefully. Never use materials from unmarked containers – they may give off poisonous vapours.

Never run the engine of a motor vehicle in an enclosed space such as a garage. Exhaust fumes contain carbon monoxide which is extremely poisonous; if you need to run the engine, always do so in the open air or at least have the rear of the vehicle outside the workplace.

## The battery

Never cause a spark, or allow a naked light, near the vehicle's battery. It will normally be giving off a certain amount of hydrogen gas, which is highly explosive.

Always disconnect the battery earth (ground) terminal before working on the fuel or electrical systems.

If possible, loosen the filler plugs or cover when charging the battery from an external source. Do not charge at an excessive rate or the battery may burst.

Take care when topping up and when carrying the battery. The acid electrolyte, even when diluted, is very corrosive and should not be allowed to contact the eyes or skin.

If you ever need to prepare electrolyte yourself, always add the acid slowly to the water, and never the other way round. Protect against splashes by wearing rubber gloves and goggles.

## Mains electricity and electrical equipment

When using an electric power tool, inspection light etc, always ensure that the appliance is correctly connected to its plug and that, where necessary, it is properly earthed (grounded). Do not use such appliances in damp conditions and, again, beware of creating a spark or applying excessive heat in the vicinity of fuel or fuel vapour. Also ensure that the appliances meet the relevant national safety standards.

## Ignition HT voltage

A severe electric shock can result from touching certain parts of the ignition system, such as the HT leads, when the engine is running or being cranked, particularly if components are damp or the insulation is defective. Where an electronic ignition system is fitted, the HT voltage is much higher and could prove fatal.

## Routine maintenance

Periodic routine maintenance is a continuous process that commences immediately the machine is used. It must be carried out at specified mileage recordings or on a calendar basis if the machine is not used frequently, whichever is sooner. Maintenance should be regarded as an insurance policy, to help keep the machine in the peak of condition and to ensure long, trouble-free service. It has the additional benefit of giving early warning of any faults that may develop and will act as a safety check, to the obvious advantage of both rider and machine alike.

The various maintenance tasks are described below, under their respective mileage and calendar headings. Accompanying diagrams are provided, where necessary. It should be remembered that the interval between the various maintenance tasks serves only as a guide. As the machine gets older or is used under particularly adverse conditions, it would be advisable to reduce the period between each check.

No special tools are required for the normal routine maintenance tasks. The tools contained in the toolkit supplied with every new machine are limited, but will suffice if the owner wishes to carry out only minor maintenance tasks.

When buying tools, it is worth spending a little more than the minimum to ensure that good quality tools are obtained. Some of the cheaper tools are too soft or flimsy to do an adequate job. It is infuriating to have to stop part way through a job because a spanner has splayed open or broken, and a replacement must be found.

A deep rooted knowledge of engineering principle is by no means necessary before the owner undertakes his or her own maintenance tasks but familiarity with a few of the more commonly used terms and a basic knowledge of how to use tools will help.

The following list of tools will suffice to undertake the routine maintenance tasks described in this Section, but where reference is made to another Chapter for the dismantling procedure, additional tools may be required.

- A tyre pressure gauge.
- A tyre pump
- A 10 mm or 12 mm spark plug spanner
- A set of metric open ended spanners from 6 mm to 17 mm
- A pair of pliers
- Two cross head screwdrivers, size 2 and 3
- A small electrical screwdriver
- A set of feeler gauges
- A 23 mm box or ring spanner
- A 3 mm square socket (Honda tool)
- An adjustable spanner (this tool to be used only as a last resort)

### Weekly or every 200 miles (320 km)

#### 1 Check the tyre pressures

The tyre pressure should be 26 psi for the front tyre and 29 psi for the rear tyre measured when the tyres are cold.

Remove the dust cap. Flick the valve centre to blow out any dirt or water and push on the pressure gauge. If the pressure is too low, pump up the tyre with the pump or a garage air line to the correct pressure. If the pressure is too high, push the valve centre to release the air until the correct pressure is reached.


Replace the dust cap as it is a second seal.



Check the tyre pressures

#### 2 Check the engine oil level

The engine oil capacity is 0.8 litres C50 model, 0.7 litre C70 model and 0.9 litre C90 model (1.4, 1.2 and 1.6 pints respectively) contained in a wet sump, and normally SAE 20W/50 but in a cold climate SAE 10W/30 should be used.



Place the machine on its centre stand on level ground. If the machine has just been run, allow the oil to settle for 5 minutes before checking the level. Remove the plastic filler cap with its integral dipstick. Wipe the oil off the dipstick. Replace the dipstick without screwing it in, remove it and check that the oil level is between the upper and lower limit marks on the dipstick. Add oil if necessary, to bring the oil to the correct level, and replace the filler cap dipstick after ensuring that the sealing O-ring is in good condition.







Oiling the front brake lever



Oiling the rear brake adjuster



Oiling a control cable



Frame is marked to aid wheel alignment

### 3 Oil and adjust the brake cables and rod

The standard brake cables should be lubricated with a light machine oil, but if a nylon lined cable has been fitted on no account use oil on it.

Similarly, the cable nipples and pivot points should be oiled including those of the brake rod. Normally, rain and the washing of the machine will provide sufficient lubrication for the nylon and plastic parts. Before the winter sets in each year, it is advisable to remove the cables completely and thoroughly lubricate them as shown in the accompanying sketch, to ensure troublefree riding during the more arduous conditions to be found in winter.

The brakes need adjusting when there is too much movement on the lever or the pedal i.e. when the brake lever comes close to the handlebar when the brake is applied or if there is too much movement of the brake pedal. To adjust either brake turn the adjusting nut until the brake just starts to rub when the wheel is spun. Slacken back the adjusting nut until the brake just stops rubbing. Ensure that the adjusting nut cut-outs are seating correctly on the brake operating arms.

### 4 Check, adjust and lubricate the final drive chain

Place the machine on its centre stand on level ground. Check the up and down movement of the chain, midway between the two sprockets. Rotate the back wheel until the up and down movement is at the minimum. This is the 'tight spot' on the chain and the up and down movement here should be between 10 mm (0.40 inch) and 20 mm (0.79 inch).

If the play is greater than 20 mm (0.79 inch) the chain should be adjusted as follows:

Slacken the wheel spindle nuts so that they are finger tight. Make sure that each adjusting nut is turned the same amount, to keep the wheels in line, until the play is reduced to within the limits. Tighten the wheel spindle nuts and recheck the amount of play on the chain.

When the wheels are properly aligned both the adjusters should match the swinging arm markings.

An SAE 90 oil or a Chain Lubricant should be spread on the chain for lubrication. The latter is applied from an aerosol pack, to make application easier.

### 5 Check the lights and horn

Check that all the lights are working properly. Renew any defective bulbs and if any lights are dim, clean the connections and earthing points, to restore the lights to their original brightness.


Check that the horn works, again checking the connections if the performance is poor.

### 6 Visual inspection

Give the whole machine a close visual inspection, checking for loose nuts and fittings, frayed control cables or missing parts which may have fallen off or been stolen.



Lubricating the chain



The larger bolt is the drain plug

### 7 Check the battery

Remove the side panel, release the battery and slide it out. Remove the top cover, if fitted, and unscrew the three vent plugs on top of the plates. On translucent batteries, the level of the liquid is marked on the outside of the battery. If the liquid level is low, the three separate cells in the battery should be topped up to the correct level with distilled water. Tap water should not be used as the impurities in the water will have an adverse effect on the battery life.

Replace the three plugs and the cover and refit the battery to the machine, finally replacing the side panel.

If any liquid is spilt out of the battery this should be washed off immediately with plenty of water as it will corrode any metal parts and burn the skin if left unattended.

### Monthly or every 1000 miles (1600 km)

Check the tyres, brakes, lights and horn as described in the weekly/200 miles service and then carry out the following additional tasks:

#### 1 Change the engine oil

As stated previously the engine oil capacity is between 0.7 and 0.9 litres (1.3 and 1.6 pints) of SAE 20W/50 oil, the precise quantity depending on the model.

Place the machine on its centre stand on level ground. Run the engine for a few minutes to warm up the oil so that it will run out easier. Place a container under the engine and remove the drain plug, which is situated on the underside of the engine. When all the oil has drained, replace and tighten the drain plug, ensuring that the sealing washer is in good condition.

Refill the engine with oil of the correct viscosity, checking the level as described in the weekly check.

#### 2 Check the spark plug

An NGK type C-7HS or D-6HN spark plug is fitted as standard equipment to the Honda C50, C70 and C90. The recommended gap of the plug is 0.6 mm (0.024 inch) to 0.7 mm (0.028 inch).

Pull off the spark plug cap and unscrew the plug. Clean the electrode to remove any oil or carbon. Check the gap between the electrode with a set of feeler gauges. If the gap needs resetting, bend the outer electrode to bring it closer to the central electrode. Do not try to move the centre electrode as the insulation will break and ruin the plug.

Refit the spark plug and push on the plug cap. Do not over-tighten the spark plug as this can cause the thread to strip in the cylinder head. A normal plug spanner has the correct length 'pinny' bar or handle to make overtightening impossible.

A new spark plug should be fitted every 5,000 miles (8,000 km), or if it is damaged or excessively worn.

#### 3 Check and adjust the throttle cable

The throttle should have about 10° free play movement. To adjust the amount of free play, slide the rubber sleeve cable, to reveal the adjusting nut. The adjusting nut is turned to provide the correct play and the rubber sleeve, when slid back down the cable, stops the adjusting nut from turning.

#### 4 Check and adjust the carburettor slow running adjustment

Any checks or adjustments that are made on the carburettor should be undertaken only when the engine has reached its normal working temperature and not when the engine is cold.

The engine should continue to run slowly when the throttle is closed. If the engine stops every time the throttle is closed, adjustment is necessary. As the machine has an automatic clutch, if the engine runs too fast, the machine will tend to creep forward when it is in gear unless the brakes are applied to stop it.

Slacken the throttle cable to ensure that there is plenty of slack so that cable tension does not give false adjustment on the carburettor.

On the side of the carburettor are two screws, the upper one is the throttle stop screw, the lower the air mixture screw.

To adjust the slow running of the engine, turn the throttle stop screw until the engine is running at approximately 1500 rpm.



Refilling the engine with oil

Turn the air mixture screw until the highest engine speed is obtained. If the engine speed is then too fast, unscrew the throttle stop screw to reduce it, then turn the air mixture screw to find the highest engine speed again. This process is repeated until the engine runs slowly and evenly. Readjust the throttle cable slack to the limit as set out under the previous heading.

#### 5 Check the tyre condition

By law a motorcycle must have a minimum depth of tread of 1 mm (0.04 inch) for at least 75% of the tyre width all the way round the circumference of the tyre. In the interest of safety it is better to renew the tyre long before the legal minimum is reached.

When checking the tyre condition, remove any stones in the tread, check for any bulges, splits or bald spots and renew the tyre if any doubt exists by following the procedure given in Chapter 6, Section 17.

#### 6 Check the clutch adjustment

The clutch plates will wear inside the clutch and the adjustment should be checked periodically to ensure that smooth gearchanging continues.

Clutch adjustment is provided by means of an adjustable screw and locknut located in the centre of the clutch cover. Slacken off the 10 mm locknut and turn the adjusting screw firstly in a clockwise direction, to ensure there is no end pressure on the clutch pushrod.

Turn the adjusting screw anticlockwise until pressure can be felt on the end. Turn back (clockwise) for approximately 1/8th of a turn, and tighten the locknut, making sure the screw does not turn. Clutch adjustment should now be correct.

### Six monthly or every 3,000 miles (5,000 km)

Complete all the checks under the weekly and monthly headings and then the following items.

#### 1 Clean the air filter

The air filter is located on top of the main frame tube, immediately behind the steering head, clearly visible when the legshield has been removed.

To clean the air filter, remove the detachable element and tap it lightly to remove accumulated dust. Blow dry from the inside with compressed air, or brush the exterior with a light brush. Remember the element is made from paper. If it is torn or damaged, fit a replacement.

Oil or water will reduce the efficiency of the filter element and may upset the carburettor. Replace any suspect element.

It is advisable to replace the element at less than the recommended 6,000 miles if the machine is used in very dusty conditions. The usual signs of a filter element in need of replacement are reduced performance, misfiring and a tendency for the carburation to run rich.

On no account should the machine be run without the filter element in place because this will have an adverse effect on carburation. Reassembly of the air filter is the reverse of the dismantling procedure.

#### 2 Clean the carburettor and filter

Over a period of time sediment and water will collect in the carburettor. A drain screw on the carburettor enables the float chamber to be flushed out with petrol to remove nearly all of the dirt but Chapter 3 Sections 7 to 10 will describe how the carburettor itself is removed, stripped, cleaned and reassembled, if any trouble still persists.

#### 3 Remove, clean and lubricate the final drive chain

Although the final drive chain is fully enclosed, the oil and grease lubricant on the chain will tend to pick up dust and grit, so every six months it is advisable to remove the chain from the machine for thorough cleaning.

To remove the chain, place the machine on its centre stand on level ground, remove the four bolts and the two chaincase halves and rotate the rear wheel until the spring link is in a convenient position, preferably on the rear wheel sprocket. Use a pair of pliers to remove the spring clip and then remove the side plate and the link plate, thus disconnecting the chain.

Connect to one end of the chain a second chain, either an old worn out one or a brand new one which is kept in readiness for fitting to the machine. Pull the first chain off the machine, feeding the second chain on, until the first chain can be disconnected from the second chain. If the second chain is usable, reconnect it, ensuring that the closed end of the spring clip is facing the direction of travel of the chain. Adjust the chain as described in the weekly maintenance section and refit the chaincase.

The chain which has just been removed should be washed thoroughly in petrol or paraffin to remove all the dirt and grease.

To check whether the chain is due for renewal, lay it lengthwise in a straight line and compress it so that all play is taken up. Anchor one end and then pull on the other end to take up the play in the opposite direction. If the chain extends by more than the distance between two adjacent links, it should be renewed in conjunction with the sprockets.

The chain should be lubricated by immersing it in a molten lubricant such as Linklife or Chainguard and then hanging it up to drain. This will ensure good penetration of lubricant between the pins and rollers, which is less likely to be thrown off when the chain is in motion.

To refit the chain to the machine, connect it to the second chain, pull the second chain and feed the first chain back onto the machine. Reconnect the chain ensuring the spring clip is correctly fitted as stated before. It is easier to reconnect the chain if the ends are fitted onto the rear wheel sprocket whilst the connecting link is inserted. Adjust the chain, using the weekly maintenance procedure, and refit the chaincase.

#### 4 Check and adjust the valve tappet clearances

The valve tappet clearance for both the inlet and exhaust valves is 0.05 mm (0.002 inch) when the engine is cold.

A small amount of dismantling is required before the tappet clearance can be checked.

Ensure that the machine is on its centre stand, standing on level ground. Remove the flywheel inspection cover on the left-hand side of the engine. Remove also the two tappet covers to reveal the adjusters.

To check the tappet clearances, turn the flywheel until the line marked with a 'T' is aligned with the mark on the flywheel cover. The piston will now be at top dead centre on either the compression or exhaust stroke. Checking the tappet clearances must be made on the compression stroke when both rocker arms are free to rock, so a complete turn of the flywheel is required if the piston is on the exhaust stroke. It will probably be found that when turning the flywheel, the 'T' mark tends to move on every other revolution when the piston is under compression. This is the position required for checking the tappet clearances and to avoid the 'T' mark moving, removing the spark plug and its cover will relieve the pressure in the cylinder.


A 0.05 mm (0.002 inch) feeler gauge should just pass between the rocker arm and the valve stem. If adjustment is necessary, slacken the locking nut and turn the adjusting screw until the feeler gauge will just pass through the gap. Hold the adjusting screw securely and retighten the locknut. Check the gap again to ensure that it is still correct. This applies to both valves as the clearance is identical.

Refit the tappet covers, checking the condition of the O-rings. Refit the spark plug, the plug cover and the flywheel cover, unless the next task of checking the ignition timing is about to be carried out.

#### 5 Check and adjust the ignition timing

C50 and C70 models only: The ignition timing is determined by when the contact breaker points open. The flywheel operates the contact breaker and the heel of the contact arm will wear, altering the ignition timing. The flywheel inspection cover should be removed so that the contact breaker can be viewed through one of the apertures in the flywheel. When the line marked 'F' on the flywheel lines up with the mark on the crankcase shaft, the contact breaker should just start to open. If adjustment is necessary, the fixed contact can be moved by slackening the clamping screw and using a screwdriver in the slot provided. Retighten the clamping screw and check the adjustment again, to ensure that it has not altered.





Align the 'T' mark with the mark on the cover

When the ignition timing is correct, rotate the flywheel to determine the position at which the contact breaker points are fully open. When fully open the contact breaker gap should be between 0.3 mm and 0.4 mm (0.012 and 0.016 in).

If the gap is too small, the contact breaker points need renewing, as described in Chapter 4 Section 6.

Refit the flywheel cover and the spark plug and plug cover, if these have been removed.

**C90 model only:** The ignition timing is determined by when the contact breaker points open. The camshaft operates the contact breaker and the heel of the contact arm will wear, altering the ignition timing. The flywheel inspection cover and the contact breaker cover must be removed. Before checking the ignition timing, the contact breaker gap should be checked. Rotate the engine until the contact breaker is in its fully open position. Check the gap to see if it is between 0.3 and 0.4 mm (0.012 and 0.016 inch). To adjust the gap, slacken the two screws that hold the contact breaker assembly, and using a small screwdriver in the slot provided ease the assembly to the correct position. Tighten the screws and recheck the gap to ensure that the assembly has not moved.

The ignition timing is correct when the contact breaker points are about to separate when the 'F' line scribed on the flywheel rotor coincides exactly with the mark on the cover. The backplate holding the complete contact breaker assembly is slotted, to permit a limited range of adjustment. If the two crosshead retaining screws are slackened a little, the plate can be turned until the points commence to separate, and then locked in this position by tightening the screws.


After checking the timing, rotate the engine and check again before replacing the covers. The accuracy of the ignition timing is critical in terms of both engine performance and petrol consumption. Even a small error in setting can have a noticeable effect on both.

#### 6 Check the centre and prop stand springs


Check the condition of the centre and prop stand springs and renew them if they are worn or heavily corroded. If the stand drops when the machine is moving, it may catch in some obstacle in the road and unseat the rider. Grease the springs and the stand pivot points.

#### 7 Grease the speedometer cable

Once the headlamp lens has been removed the speedometer cable can be unscrewed from the speedometer head and pulled clear. The inner cable can then be pulled out. Clean off the old grease by washing in petrol or paraffin. Spread new grease along the length of the cable except for the top 15 cm (6 inch) and feed the cable back into the outer casing. Reconnect the cable to the speedometer head.




Use a feeler gauge to check the gap




Align the 'F' mark with the mark on the cover




Check the return spring condition




Greasing the suspension pivots



Greasing the leading link fork pivots




Remove the switch assembly to release the twistgrip



Slide the twistgrip off for greasing



Remove the sliding block to oil the cable



Oil the first seal.



If the top of the cable is greased, the grease will work its way into the speedometer head and stop it functioning, thus necessitating a replacement as the speedometer head cannot be stripped for cleaning.

#### 8 Grease the leading link forks

Apply a grease gun to the nipples on the leading links and the fork blades. Pump grease into the bearings until clean grease emerges from the joints. Wipe away any excess grease as this will collect the dirt and make the machine look unsightly.

#### 9 Grease the throttle twistgrip and oil the throttle cable

Remove the two screws and the indicator switch from the handlebar. This releases the twisting sleeve which slides off the handlebar with an anti-clockwise twist. The sliding block can now be lifted out of the handlebar and the inner cable unhooked. The outer cable stop can then be removed from the handlebar and unhooked from the cable.

#### 10 Adjust the camshaft chain tension

Before attempting to adjust the camshaft chain tension, it should be noted that three different types of camshaft chain tensioner assembly are used within the range of models, one being of an automatic type and the other two being of a manual type. To recognise the automatic tensioner, look for a blank sealing plug with a hexagon-shaped head located on the forward part of the underside of the left-hand crankcase. A similar sealing plug exists for one of the manual tensioners but this is accompanied by a slotted adjuster stud and locknut located just forward of the gearchange pedal shaft. The remaining type of manual tensioner may be recognised by the slotted end of the adjuster screw which is visible in the centre of a sealing plug which takes the place of the blank types previously described. Reference should be made to Figs. 1.13 and 1.14 of Chapter 1 when determining the type of tensioner fitted. Details of removing and inspecting the component parts of the automatic tensioner are given in Section 33 of Chapter 1; the method of adjusting the manual tensioners being as follows.

Before adjustment of either type of manual tensioner is made, the engine should be started and allowed to run until it reaches normal operating temperature. With the engine set to idle at  $1500 \pm 100$  rpm, proceed to adjust the type of tensioner fitted as follows.

Where the tensioner is of the type with the slotted adjuster screw located in the centre of the sealing plug, adjustment is made simply by unscrewing the screw approximately  $\frac{1}{4}$  of a turn. This allows the two collars within the tensioner to release their grip on the guide rod, thus allowing the rod to move under pressure from the spring; this in turn pushes the pushrod against the tensioner ring thereby tensioning the chain. Retighten the adjuster screw and the adjustment is complete.

The remaining type of manual tensioner is adjusted by loosening the locknut located just forward of the gearchange pedal shaft and unscrewing the screw approximately  $1\frac{1}{2}$  turns.



Release the tensioner pushrod by unscrewing the locknut and screw

This will release the pushrod and allow it to bear against the tensioner arm under pressure from the springs, thereby tensioning the chain. Complete the adjustment procedure by tightening both the screw and locknut. If excessive noise from the chain persists, then the screw and locknut should be left loose and the sealing plug removed from the crankcase to allow access to the slotted adjuster located beneath it. Screw in this adjuster until the noise from the chain ceases and then retighten the screw and locknut. Before reinserting the sealing plug, screw in on the slotted adjuster to preload the tensioner spring. This will make any subsequent adjustment easier in that it will only be necessary to loosen and retighten the locknut and screw. It should be noted that additional pre load will not diminish the noise produced by a badly worn chain and cam sprockets. The additional adjustment facility provided should be used only for removal of noise caused by a slack chain in good condition.

#### Yearly or every 5,000 miles (8,000 km)

Complete all the checks listed under the weekly, monthly and six monthly headings, then complete the following additional tasks:

#### 1 Lubricate the felt wick of the contact breaker cam

When the ignition timing is checked, the felt wick of the contact breaker cam can be seen. A few drops of light machine oil, should be put on the wick to reduce wear on the heel of the contact arm. Do not over oil. If oil finds its way on to the contact breaker points it will act as an insulator and prevent electrical contact from being made.

#### 2 Check the condition of the sprockets

When the final drive chain is cleaned and checked, ensure that the sprockets are not badly worn, before replacing the chain. If the sprocket teeth are badly worn, they will probably have a hooked appearance and should be renewed as described in Chapter 1 Sections 16 and 47 and Chapter 6 Section 12.

#### 3 Adjust and lubricate the steering head bearings

Dismantling and reassembly of the steering head is a task that should be undertaken only if a good understanding of the problems involved is realised. Chapter 5 Sections 2 and 4, fully describe the necessary procedures.

#### 4 Examine and lubricate the wheel bearings

Dismantling and reassembly of the wheel bearings is also a task to be undertaken only if an understanding of the problems involved is realised. Chapter 6 fully describes the necessary procedure.

#### 5 Examine both front and rear brake assemblies

The brake assemblies should be cleaned to remove any dust and checked to ensure that the brake linings are not wearing too thin. This task is fully described in Chapter 6.



Screw in on the adjuster until chain noise ceases

Although this manual shows how components can be removed and replaced without the use of special service tools (unless absolutely essential), it is worthwhile giving consideration to the purchase of the more commonly used tools if the machine is regarded as a long term purchase. Whilst the alternative methods suggested will remove and replace parts without risk of damage, the use of the special tools recommended and sold by the manufacturer will invariably save time.




## 1 General description

The Honda C50, C70 and C90 models are fitted with an overhead camshaft engine in which the valve mechanism is chain driven. The camshaft is located within the aluminium alloy cylinder head; with this arrangement it is necessary to disturb the valve timing when the cylinder head is removed.

All engine/gear units are of aluminium alloy construction, with a cast iron cylinder barrel. The flywheel generator is mounted on the left-hand side of the engine unit; the clutch assembly is located on the right-hand side of the engine, behind a domed aluminium alloy cover. Convention is defied by installing the engine/gear unit in a near-horizontal position, so that the cylinder barrel is almost parallel to the ground. The exhaust system is carried on the right-hand side of the machine, of the down-swept pattern. All models are fitted with a conventional kickstart.

A trochoid oil pump is included in the general specification of the engine, to provide a pressure oil feed in addition to lubrication by splash. There are also two filters in the lubrication system, a gauze screen in the crankcase and a centrifugal filter within the clutch centre.

The engine is built in unit with the gearbox. This means that when the engine is dismantled, the gearbox has to be dismantled too, and vice-versa.




5.3 Remove the air cleaner lid

## 2 Operations with engine/gearbox in frame

It is not necessary to remove the engine unit from the frame unless the crankshaft assembly and/or the gearbox bearings require attention. Most operations can be accomplished with the engine in place, such as:

- 1 Removal and replacement of cylinder head.
- 2 Removal and replacement of cylinder barrel and piston.
- 3 Removal and replacement of flywheel magnetic generator.
- 4 Removal and replacement of clutch assembly.
- 5 Removal and replacement of timing pistons and kickstart assembly.

When several operations need to be undertaken simultaneously, it will probably be advantageous to remove the complete engine unit from the frame, an operation that should take approximately twenty minutes. This will give the advantage of better access and more working space.



5.4a Slacken the nuts and remove the clamping band ...

## 3 Operations with engine/gearbox removed

- 1 Removal and replacement of the main bearings.
- 2 Removal and replacement of the crankshaft assembly.
- 3 Removal and replacement of the gear cluster, selectors and gearbox main bearings.

## 4 Method of engine/gearbox removal

As described previously, the engine and gearbox are built in unit and it is necessary to remove the complete unit in order to gain access to either component. Separation is accomplished after the engine unit has been removed and relitting cannot take place until the crankcase has been reassembled.

## 5 Removing the engine/gearbox unit

- 1 Place the machine on the centre stand and make sure it is standing firmly, on level ground.
- 2 Remove the side panels to obtain the tool kit and reveal the battery. Unscrew the fuse holder and remove the fuse, to isolate the battery.
- 3 Remove the domed nut and the air cleaner lid and withdraw the element.




5.4b ... followed by the other bolts and spacers







5.6 Release the exhaust pipe from the cylinder




5.8 Remove the gearchange lever



5.10 Disconnect the wires at the snap connectors



5.11 Remove the spark plug cap and HT lead clip



5.12 Disconnect the brake and stoplight springs

- 4 Slacken the nuts holding the rear of the plastic legshields and remove the clamping band, if fitted. Remove the four bolts holding the legshields and pull their spacers clear. The legshields will now lift clear, allowing easy access to the engine.
- 5 Remove the crankcase drain plug and drain the oil into a suitable container.
- 6 Remove the two nuts holding the exhaust pipe to the cylinder head and unscrew the swinging arm pivot nut to release the silencer. The exhaust system will then pull clear, pulling the two collars out of the cylinder head. Remove the copper/asbestos joint ring from the exhaust port.
- 7 Ensure that the petrol is switched off and remove the nuts clamping the carburettor to the cylinder head. The carburettor can be left in place when the engine is dropped out of the frame.
- 8 Remove the gearchange lever clamp bolt and slide the lever off its shaft.
- 9 Remove the three screws and the flywheel generator cover or two screws and rear cover on the C90 model, to reveal the final drive sprocket. Rotate the rear wheel until the chain spring link is in a removable position. Disconnect the chain at the spring link and pull the chain clear of the engine sprocket. If the chain is reconnected, it will ease finding both ends of the chain when reassembling. It may be necessary to remove two bolts and the top half of the chainguard to obtain greater access to the chain.



10 Pull the snap connectors apart to disconnect the engine wires. All of them are colour coded for easy reconnection.

11 Pull off the spark plug cap and remove the screw to release the HT lead.

12 Unhook the brake pedal and stop lamp switch springs.

13 Remove the footrest assembly, which is attached to the crankcase by four 14 mm bolts and spring washers. It is possible to remove the engine/gear unit with the footrests in place, if it is desired to use them as a convenient carrying handle.

14 Remove the top engine bolt and allow the engine to pivot down. Ensure that the carburettor has slid off its studs and is clear of the engine. Remove the bottom engine bolt and pull the engine clear of the machine. Note that the C90 model has an inlet tube bolted to the cylinder head which can either be removed or left attached to the carburettor.

## 6 Dismantling the engine and gearbox: general

Before commencing work on the engine unit, the external surface should be cleaned thoroughly. A motor cycle engine has very little protection from road grit and other foreign matter, which will find its way into the dismantled engine if this simple precaution is not observed. One of the proprietary engine cleaning compounds such as 'Gunk' or 'Jizer' can be used to good effect, particularly if the compound is allowed to work into the film of grease and oil before it is washed away. When washing down, make sure that water cannot enter the carburettor or the electrical system, particularly if these parts have been exposed.


Never use undue force to remove any stubborn part, unless mention is made of this requirement. There is invariably good reason why a part is difficult to remove, often because the dismantling operation has been tackled in the wrong sequence.

Dismantling will be made easier if a simple engine stand is constructed that will correspond with the engine mounting points. This arrangement will permit the complete unit to be clamped rigidly to the work bench, leaving both hands free.

## 7 Dismantling the engine and gearbox: removal of generator

### Engine in the frame


As stated in Section 2 of this Chapter, it is possible to remove the generator whilst the engine is still in the frame. Only paragraphs 1 to 5, 8 and 10 of Section 5 need to be completed before proceeding with the following dismantling procedure:




5.14a Remove the top engine bolt ...



5.14b ... followed by the bottom engine bolt




7.2 Remove the rotor nut




7.3 Method for removing the rotor when special service tool is not available



7.4 Release the wire on the neutral switch



7.6 Remove the stator plate and take care not to lose the Woodruff key



8.2 Remove the circular cover

**Engine removed from the frame**

If the whole of Section 5 has been completed, continue with the following dismantling procedure:

**C50 and C70 models only**

- 1 Remove the three screws and the generator cover.
- 2 Hold the generator securely and remove the central nut and washer.
- 3 Use a Honda extractor tool to remove the rotor as it is a keyed taper fit. If the extractor is not available, it may be possible to use the method shown in the accompanying photograph. Wrap some emery cloth round the rotor and clamp onto the rotor two hose clips joined end to end. A two legged sprocket puller hooked onto the hose clips can then be used to pull off the rotor.
- 4 Disconnect the green/red striped wire from the neutral indicator switch.
- 5 Remove the two countersunk crosshead screws holding the stator plate to the crankcase and remove the stator plate complete with wires. If scribe marks are made across the stator plate and its housing, this will aid reassembly and may obviate the need to retune the ignition.
- 6 Remove the Woodruff key from the crankshaft, and collect the two small O-rings that seal the stator plate screws.

**C90 model only**

- 7 Remove the two screws and the final drive sprocket cover. This allows the eight screws and the generator cover to be removed.
- 8 Disconnect the green/red striped wire from the neutral indicator contact and remove the complete stator coil assembly from the left hand crankcase by unscrewing the crosshead screws.
- 9 Hold the rotor stationary and remove the centre retaining bolt and washer.
- 10 Use a Honda extractor tool to remove the rotor. If the correct service tool extractor is not available, use a sprocket puller on a bolt screwed part way into the end of the crankshaft.

**8 Cylinder head and cylinder: removal****Engine in the frame**

As stated in Section 2 of this Chapter, it is possible to remove the cylinder head and the cylinder barrel whilst the engine is still in the frame. Only paragraphs 1 to 7 of Section 5 need to be completed before proceeding with the following dismantling procedure:

**Engine removed from the frame**


If the whole of Section 5 has been completed continue with the following dismantling procedure:

**C50 and C70 models only**


- 1 Remove the spark plug cap and unscrew the spark plug.
- 2 Remove the long bolt which passes through the centre of the camshaft and pull off the circular side cover on the left hand side of the cylinder head.
- 3 Rotate the engine until the 'O' mark on the camshaft sprocket lines up with the notch on the cylinder head. This ensures that the engine is at top dead centre (TDC) on the compression stroke.
- 4 Remove the sealing plug and the camchain tensioner spring from the underside of the engine.
- 5 Remove the three bolts and the camshaft sprocket from the end of the camshaft.
- 6 Remove the four nuts and washers from the top of the engine, noting the position of the domed nuts and sealing washers. The top engine cover will now lift clear.
- 7 Remove the single bolt on the left hand side of the engine and slide the cylinder head up the holding down studs, allowing the camshaft sprocket to drop clear of the cylinder head.
- 8 Remove the sprocket from the chain and remove the cylinder head gasket and its associated 'O' rings.
- 9 Remove the bearing bolt for the camchain guide roller and pull the roller clear.
- 10 Remove the single bolt on the left hand side of the engine and



8.4 Remove the tensioner spring



8.5 Remove the three camshaft bolts




8.6 Remove the nuts and top cover



8.7 Slide the cylinder head up the studs



8.8 Remove the camshaft sprocket



8.10 Part the crankcase mouth and slide off the barrel




Fig. 1.1. Cylinder head covers - C70 model

- 1 Top cover
- 2 Right-hand cover
- 3 Left-hand cover
- 4 Tappet cover (2 off)
- 5 Top cover gasket

- 6 Right-hand cover gasket
- 7 Left-hand cover gasket
- 8 Insulator block gasket
- 9 Insulator block
- 10 Washer (3 off)

- 11 Washer (2 off)
- 12 O-ring (2 off)
- 13 Bolt
- 14 Screw (2 off)
- 15 Nut (3 off)

- 16 Dome nut (3 off)
- 17 Washer (2 off)
- 18 Spark plug




Fig. 1.2. Cylinder head and barrel - C70 model

- |                        |                          |                       |                  |
|------------------------|--------------------------|-----------------------|------------------|
| 1 Inlet valve guide    | 5 Cylinder head assembly | 9 Rubber seal (2 off) | 13 Stud (2 off)  |
| 2 Exhaust valve guide  | 6 Cylinder head gasket   | 10 O-ring (2 off)     | 14 Screw         |
| 3 Cylinder barrel      | 7 Oip                    | 11 Rubber seal        | 15 Dowel (2 off) |
| 4 Cylinder base gasket | 8 Bolt (2 off)           | 12 Stud (2 off)       | 16 Dowel (2 off) |






Fig. 1.3. Cylinder head and barrel - C90 model

- |                        |                            |                   |                  |
|------------------------|----------------------------|-------------------|------------------|
| 1 Cylinder barrel      | 10 Right-hand cover gasket | 19 Gasket (2 off) | 28 Dome nut      |
| 2 Cylinder base gasket | 11 Camchain tunnel gasket  | 20 Clip           | 29 Dowel (2 off) |
| 3 Cylinder head        | 12 Camchain tunnel gasket  | 21 Washer         | 30 Dowel         |
| 4 Cylinder head gasket | 13 Insulator block gasket  | 22 Washer (3 off) | 31 Screw         |
| 5 Gasket               | 14 Insulator block         | 23 O-ring (2 off) | 32 Screw (3 off) |
| 6 Top cover            | 15 Insulator block         | 24 Bolt (2 off)   | 33 Spark plug    |
| 7 Right-hand cover     | 16 Clip                    | 25 Stud (2 off)   |                  |
| 8 Tappet cover (2 off) | 17 Clip                    | 26 Nut (2 off)    |                  |
| 9 Top cover gasket     | 18 Inlet pipe              | 27 Nut (3 off)    |                  |

slide the cylinder barrel up the holding down studs sufficiently to enable the crankcase mouth to be padded with a clean rag to stop any broken pieces or dirt falling inside the engine which would necessitate further engine dismantling to remove them. Slide the cylinder barrel further up the studs and support the piston as it falls clear of the barrel. Remove the barrel completely followed by the cylinder base gasket and 'O' ring.

#### *C90 model only*

The contact breaker assembly of this model is located within the cylinder head casting, where it is driven from an extension of the overhead camshaft. In consequence, a special dismantling procedure is necessary, as follows.


- 11 Remove the circular contact breaker cover on the cylinder head, held by two crosshead screws.
- 12 Disconnect the lead wire to the contact breaker assembly and remove the contact breaker assembly complete with back plate. It is retained in position by two crosshead screws, which should be removed. If the exact position of the back plate is marked with a scribe line in relation to its housing, this will aid reassembly and possibly obviate the need to retune the ignition.
- 13 Remove the automatic advance unit by withdrawing the hexagon head bolt from the centre of the camshaft. Remove also the dowel pin, which is used to ensure the assembly is replaced in the correct position.
- 14 Detach the contact breaker outer casting and gasket, which is held to the cylinder head casting by three crosshead screws.
- 15 Remove the spark plug cap and unscrew the spark plug.
- 16 Rotate the engine until the 'O' mark on the camshaft sprocket lines up with the notch on the cylinder head. This ensures that the engine is at top dead centre (TDC) on the compression stroke.
- 17 Remove the sealing plug and the camchain tensioner spring from the underside of the engine.
- 18 Remove the two bolts and pull the camshaft clear of the head leaving the chain and sprocket within the cylinder head.
- 19 Remove the four nuts and washers from the top of the engine, noting the positions of the domed nuts and sealing washers. The top engine cover will now lift clear.
- 20 Slide the cylinder head up the holding down studs, allowing the camshaft sprocket to drop clear of the cylinder head.
- 21 Remove the sprocket from the chain and remove the cylinder head gasket, the oil feed seal and the camchain tunnel seal.
- 22 Remove the bearing bolt for the camchain guide roller and pull the roller clear.
- 23 Slide the cylinder barrel up the holding down studs sufficiently to enable the crankcase mouth to be padded with a clean rag, to stop any broken pieces or dirt falling inside the engine which would necessitate further engine dismantling to remove them. Slide the cylinder barrel further up the studs and support the piston as it falls clear of the barrel. Remove the barrel completely followed by the cylinder base gasket and the camchain tunnel seal.
- 24 If the flywheel generator has been removed, the camchain can then be detached.

#### **9 Piston and piston rings: removal**

- 1 The gudgeon pin is of the fully floating type, retained by two wire circlips in the piston boxes. After the circlips have been removed, using pointed nose pliers, the pin can be tapped lightly from the piston.
- 2 Note the piston is marked with an arrow and must be positioned so that the arrow points downwards. If the piston is oversize, the amount will be stamped on the piston crown.
- 3 Remove the piston rings by expanding them gently, using extreme care because they are very brittle. If they prove difficult to remove, slide strips of tin behind them, to help ease them from their grooves. The top piston ring is of the chrome type and should have the mark 'top' on the uppermost face. The second ring is tapered and should have the 'top' mark in a similar position. A slotted oil scraper ring is fitted in the lower groove.




9.2 The piston is marked with an arrow




10.2a Use a bolt to withdraw the rocker pins ...




10.2b ... to release the rocker arms



11.3a Remove the spring register ...



11.3b ... the inner and outer valve springs ...



11.3c ... and the oil seal and cap

which can be located with either face uppermost.

#### 10 Camshaft and rocker arm: removal


- 1 The camshaft on the C50 and C70 models slides out of the cylinder head once the cam lobes have been lined up with their respective cutouts. The C90 model camshaft will have been removed in the cylinder head removal sequence.
- 2 Remove the two or three (C90 model) screws and the right-hand (finned) cover. Pull out the rocker pins by using a standard bolt screwed into the extraction thread. The engine mounting bolt is of the correct thread size. The rocker arms will now pull clear.

#### 11 Valves and valve guides: removal

- 1 Remove the two tappet covers from the cylinder head.
- 2 Use a small size valve spring compressor to compress the springs and release the two half collets.
- 3 Release the valve spring compressor and remove the top spring register, the inner and outer valve springs, and on the exhaust valve only, the bottom spring register, the oil seal cover and the oil seal.
- 4 The valve will slide out of its guide. The other valve can now be treated in exactly the same way.
- 5 If it is necessary to remove the valve guides, they can be tapped out with a hammer and drift. Warming the cylinder head will help, as the guides are a tight fit.

#### 12 Oil filters: removal

- 1 As cleaning the oil filters is part of the routine maintenance the following procedure applies when at least paragraphs 1 to 5 of Section 5 have been completed.
- 2 Remove the kickstart bolt and pull the kickstart lever clear.
- 3 Ensure that there is no oil in the engine before removing the eight (C50 and C70 models) or nine screws (C90 model) and the right-hand cover. A deluge of oil will result if this simple precaution is not taken.



11.5 The valve guide will press out of the head




Fig. 1.4. Camshaft and valves - C70 model

- |                        |                              |                              |                         |
|------------------------|------------------------------|------------------------------|-------------------------|
| 1 Camshaft             | 5 Exhaust valve              | 9 Inner valve spring (2 off) | 13 Tappet screw (2 off) |
| 2 Rocker arm (2 off)   | 6 Oil seal                   | 10 Spring retainer (2 off)   | 14 Tappet nut (2 off)   |
| 3 Rocker shaft (2 off) | 7 Seal cover                 | 11 Spring register           |                         |
| 4 Inlet valve          | 8 Outer valve spring (2 off) | 12 Collar (4 off)            |                         |





Fig. 1.5. Camshaft and valves - C9D model

- |                        |                               |                               |                         |
|------------------------|-------------------------------|-------------------------------|-------------------------|
| 1 Inlet valve guide    | 6 Inlet valve                 | 11 Inner valve spring (2 off) | 16 Dowel                |
| 2 Exhaust valve guide  | 7 Exhaust valve               | 12 Spring retainer (2 off)    | 17 Tappet screw (2 off) |
| 3 Camshaft             | 8 Oil seal                    | 13 Spring register (2 off)    | 18 Tappet nut (2 off)   |
| 4 Rocker arm (2 off)   | 9 Seal cover                  | 14 Spring register            | 19 O-ring (2 off)       |
| 5 Rocker shaft (2 off) | 10 Outer valve spring (2 off) | 15 Collet (4 off)             |                         |






12.4a Remove the clutch operating arm ...



12.4b ... and prise out the camplate



12.5 Remove the clutch outer plate to clean the filter

4 When the cover has been removed, it is probable that an anti-rattle spring will have dropped out of position. This is located between the clutch operating cam plate and the release mechanism, to eliminate chatter. Remove the washer (C50 model only) and the clutch operating lever from its splined shaft, lift off the ball bearing carrier and prise from the camplate from the centre of the clutch.

5 Remove the two (C90 model) or three (C50 and C70 models) screws that retain the clutch outer plate. This is also the centrifugal filter which may have an amount of dirt inside, so care should be taken when removing the plate to ensure that the dirt does not fall into the engine.

6 The filter gauze is located at the bottom of the engine, in a slot probably hidden by the old gasket.

### 13 Clutch and primary drive: removal

1 As stated in Section 2 of this Chapter, the clutch and primary drive can be removed whilst the engine is still in the frame but Section 12 must be completed first.

2 A special tool is now needed, preferably the Honda service tool, but a suitable equivalent can be made from a piece of tube. The tube is cut to leave two prongs which fit the special sleeve nut, as shown in the accompanying sketch.






Fig. 1.6. Clutch sleeve tool


- 1 Holes for tammy bar
- 2 Two pegs to engage with sleeve nut
- 3 Sleeve nut



13.3 Remove the sleeve nut



13.4 The clutch lifts off as a complete assembly




13.5b ... the centre bush


3. Prise out the tab washer, hold the clutch securely and use the special tool to remove the clutch centre nut.
4. The clutch will lift off as a unit and if further work on the clutch is necessary, Chapter 2 will provide all the information required.
5. Slide off from the crankshaft the primary drive pinion, the pinion bearing and the double diameter spacer.
6. Remove the circlip and slide the large primary drive pinion off its shaft.

#### 14 Gearchange mechanism: removal


1. Remove the shouldered bolt and the index arm, with the spring still attached.
2. Remove the bolt in the gearchange drum. Remove the index plate and the four operating pins.
3. The gearchange spindle assembly will now pull clear, provided that the gearchange lever has already been removed.
4. Care should be taken to see that the springs do not fall off and are lost on the floor.



13.5a Remove the primary drive pinion ...



13.5c ... and the double diameter spacer




13.3 Remove the sleeve nut

- 3 Prise out the tab washer, hold the clutch securely and use the special tool to remove the clutch centre nut.
- 4 The clutch will lift off as a unit and if further work on the clutch is necessary, Chapter 2 will provide all the information required.
- 5 Slide off from the crankshaft the primary drive pinion, the pinion bearing and the double diameter spacer.
- 6 Remove the circlip and slide the large primary drive pinion off its shaft.

#### 14 Gearchange mechanism: removal


- 1 Remove the shouldered bolt and the index arm, with the spring still attached.
- 2 Remove the bolt in the gearchange drum. Remove the index plate and the four operating pins.
- 3 The gearchange spindle assembly will now pull clear, provided that the gearchange lever has already been removed.
- 4 Care should be taken to see that the springs do not fall off and are lost on the floor.




13.4 The clutch lifts off as a complete assembly




13.5a Remove the primary drive pinion ...




13.5b ... the centre bush ...




13.5c ... and the double diameter spacer




13.6a Remove the circlip ...




13.6b ... and slide the gear off its splines




14.1 Remove the pivot bolt and index arm



14.2a Remove the index plate ...



14.2b ... and the four pins



14.3 Slide out the gearchange mechanism




Fig. 1.7. Kickstart and gearchange - C70 model


- 1 Gearchange spindle assembly
- 2 Gearchange spindle
- 3 Gearchange arm
- 4 Arm spring


- 5 Return spring
- 6 Spring stop
- 7 Pinion
- 8 Ratchet spring

- 9 Spindle
- 10 Spring retainer
- 11 Return spring
- 12 Washer


- 13 Washer
- 14 Circlip
- 15 Circlip (2 off)
- 16 Circlip








15.1a Release the circlip ...



15.1b ... and slide off the spring and retainer



16.1b ... and lift the sprocket clear

**15 Kickstart return spring: removal*****C50 and C70 models only***

1 Remove the circlip on the kickstart shaft and ease the spring retainer up the shaft whilst releasing the spring from the crankcase. Slide the spring and retainer off the shaft.

**16 Final drive sprocket: removal**


If the left-hand side cover and the final drive chain have been removed, the sprocket is released by removing the two bolts and the locking plate and pulling the sprocket off its splined shaft.

**17 Crankcases: separating**

1 If all the necessary components have been removed from the engine as previously described there are only eight screws holding the crankcases together and once these have been removed the right-hand crankcase should lift off with light tapping on the end of the crankshaft and gearshift.



16.1a Remove the bolts and the locking plate ...



17.1 After removing the screws lift the crankcase half clear




Fig. 1.9. Crankcases - C70 model

- |                                 |                                |                   |                  |
|---------------------------------|--------------------------------|-------------------|------------------|
| 1 Right-hand crankcase assembly | 4 Left-hand crankcase assembly | 7 Clip            | 12 Drain plug    |
| 2 Right-hand crankcase assembly | 5 Left-hand crankcase assembly | 8 Stud (2 off)    | 13 Screw         |
| 3 Crankcase gasket              | 6 Oil filter                   | 9 Stud (2 off)    | 14 Screw (3 off) |
|                                 |                                | 10 Sealing washer | 15 Screw (4 off) |
|                                 |                                | 11 Dowel (2 off)  | 16 Dowel (2 off) |




Fig. 1.10. Crankshaft and piston - C70 model

- 1 Crankshaft assembly
- 2 Crankshaft assembly
- 3 Piston ring set
- 4 Piston
- 5 Gudgeon pin

- 6 Circlip (2 off)
- 7 Connecting rod
- 8 Roller cage
- 9 Right-hand crankshaft
- 10 Left-hand crankshaft

- 11 Left-hand crankshaft
- 12 Crank pin
- 13 Sprocket
- 14 Spacer
- 15 Woodruff key

- 16 Woodruff key
- 17 Ball bearing (2 off)
- 18 Big-end roller (22 off)






Fig. 1.11. Gearchange drum - C70 model

- |                             |                    |
|-----------------------------|--------------------|
| 1 Selector fork             | 11 Switch assembly |
| 2 Selector fork             | 12 Switch contact  |
| 3 Selector fork pin (2 off) | 13 Retaining plate |
| 4 Pin clip (2 off)          | 14 O-ring          |
| 5 Gearchange drum           | 15 Pivot bolt      |
| 6 Gearchange drum           | 16 Washer          |
| 7 Index plate               | 17 Rubber plug     |
| 8 Index pin (4 off)         | 18 Bolt            |
| 9 Index arm                 | 19 Screw           |
| 10 Arm spring               | 20 Screw           |






18.1 Remove the crankshaft assembly



18.2 Ensure that the camchain has been removed



19.1 Remove the kickstart shaft

- 2 Never use the point of a screwdriver to aid the separation of the crankcases. It will cause irreparable damage to the jointing surfaces.
- 3 There is no need to remove either the oil pump located behind the clutch or the camshaft chain tensioner assembly found at the rear of the flywheel generator. Neither impede the separation of the crankcases.

#### 18 Crankshaft assembly: removal

- 1 The crankcase bearings are a sliding fit in the steel inserted housings in the crankcase. The crankshaft assembly, complete with bearings, should withdraw from the left-hand case without difficulty, using only light pressure.
- 2 Note that the camshaft chain will need to be pulled clear of the sprocket on the crankshaft before the crankshaft can be withdrawn.
- 3 Although it is possible to use an extractor to remove the crankshaft bearings it should be remembered that if the main bearings need replacing the big-end cannot be in the best of condition and a replacement crankshaft assembly is the safest course of action. Note that the cam chain sprocket will need to be removed before the left-hand bearing can be extracted.

#### 19 Kickstart shaft assembly: removal

- 1 On the C50 and C70 models the kickstart shaft assembly will lift straight out of the crankcase half.
- 2 On the C90 model, the kickstarter return spring must be unhooked from the crankcase before the kickstart shaft assembly will lift out of the crankcase half. Remove the kickstart return spring.

#### 20 Gear selector drum and gear cluster: removal


- 1 Remove the rubber blanking plug located at the side of the neutral indicator switch.
- 2 Remove the 10 mm bolt and washer retaining the gear selector drum in the crankcase (situated adjacent to the neutral indicator). The selector drum can now be withdrawn from the crankcase, together with the selectors and the gear cluster complete.
- 3 Care should be taken to avoid losing any shims or washers from the ends of the shafts.

#### 21 Neutral indicator switch: removal


- 1 The neutral indicator switch is retained in position with a metal clamp and a single screw.
- 2 Remove the screw and clamp and slide the switch out of the crankcase half, taking care not to damage the sealing 'O' ring.

#### 22 Camchain tensioner pulley and oil pump drive: removal


- 1 To remove the oil pump drive sprocket, hold the sprocket securely and unscrew the oil pump drive shaft. The sprocket can then be pulled clear but a note should be made regarding which way round it is fitted. The C90 model has a one-piece shaft and sprocket.
- 2 The tensioner ring on the C90 model with the tensioner pulley will lift off once the three bolts and retaining plates have been removed.
- 3 The tensioner arm on the C50 and C70 models pivots on a single shouldered bolt and removal of this bolt releases the arm.
- 4 The tensioner push rod if still in the crankcase half can now be pushed out.




20.1 Remove the bolt hidden under the rubber plug




20.2 Remove the gearbox components together




21.1 A screw and plate retain the neutral switch



22.1 Unscrew the oil pump driveshaft



22.3 Remove the pivot bolt and tensioner arm



22.4 Ensure the tensioner pushrod is pulled out




Fig. 1.12a. Gearbox components - C50 and C70 models

- 1 Mainshaft
- 2 Layshaft
- 3 Layshaft low gear
- 4 Mainshaft second gear
- 5 Layshaft second gear

- 6 Layshaft second gear
- 7 Mainshaft top gear
- 8 Layshaft top gear
- 9 Sprocket
- 10 Retaining plate

- 11 Bush
- 12 Washer
- 13 Washer
- 14 Splined washer (3 off)
- 15 Circlip (4 off)

- 16 Oil seal
- 17 Bolt (2 off)
- 18 Ball bearing (2 off)





Fig. 1.12b. Gearbox components - C90 model


- |                         |                        |                   |                 |
|-------------------------|------------------------|-------------------|-----------------|
| 1 Mainshaft             | 5 Layshaft second gear | 9 Retaining plate | 13 Circlip      |
| 2 Layshaft              | 6 Mainshaft top gear   | 10 Selector dog   | 14 Bolt         |
| 3 Layshaft low gear     | 7 Layshaft top gear    | 11 Thrust washer  | 15 Ball bearing |
| 4 Mainshaft second gear | 8 Sprocket             | 12 Spline washer  | 16 Ball bearing |



24.1 Check the condition of the oil seals



25.2 The bearings are a drive fit in the crankcases



27.2 Check the crankshaft assembly for wear

### 23 Oil pump: removal

- 1 Remove the three large screws and the oil pump assembly complete will lift clear of the right-hand crankcase.
- 2 The oil pump and the lubrication system are dealt with in Chapter 3 which includes all the necessary information on oil pump operation and renovation.

### 24 Oil seals: removal

- 1 Two oil seals are fitted in the left-hand crankcase, located at the gearbox layshaft bearing and gear lever shaft on the C50 and C70 models, whilst the C90 model has the gear lever shaft oil seal in the generator cover. There is also an oil seal on the kickstart shaft bearing in the clutch cover.
- 2 The oil seals are easily removed by prising them out of position with a screwdriver. Care should be taken to ensure the lip of the bearing housing is not damaged during this operation.

### 25 Crankshaft and gearbox main bearings: removal

- 1 The crankshaft bearings will remain on their shafts when the crankshaft assembly is withdrawn from the crankcase. A puller or an extractor will be necessary for their removal as they are a tight fit.
- 2 The gearbox bearings are a light press fit in the crankcase castings. They can be drifted out of position, using a mandrel of the correct size and a hammer.
- 3 If necessary, warm the crankcases slightly, to aid the release of the bearings.

### 26 Examination and renovation: general


- 1 Before examining the parts of the dismantled engine unit for wear, it is essential that they should be cleaned thoroughly. Use a paraffin/petrol mix to remove all traces of old oil and sludge that may have accumulated within the engine.
- 2 Examine the crankcase castings for cracks or other signs of damage. If a crack is discovered, it will require professional repair.
- 3 Examine carefully each part to determine the extent of wear, if necessary checking with the tolerance figures listed in the Specifications section of this Chapter.
- 4 Use a clean, lint-free rag for cleaning and drying the various components, otherwise there is risk of small particles obstructing the internal oilways.

### 27 Big-end and main bearings: examination and renovation

- 1 Failure of the big-end is invariably accompanied by a knock from within the crankcase that progressively becomes worse. Some vibration will also be experienced. There should be no vertical play in the big-end bearing after the old oil has been washed out. If even a small amount of play is evident, the bearing is due for replacement. Do not run the machine with a worn big-end bearing, otherwise there is risk of breaking the connecting rod or crankshaft.
- 2 It is not possible to separate the flywheel assembly in order to replace the bearing because the parallel sided crankpin is pressed into the flywheels. Big end repair should be entrusted to a Honda agent, who will have the necessary repair or replacement facilities.
- 3 Failure of the main bearings is usually evident in the form of an audible rumble from the bottom end of the engine, accompanied by vibration. The vibration will be most noticeable through the footrests.
- 4 The crankshaft main bearings are of the journal ball type. If wear is evident in the form of play or if the bearings feel rough



Fig. 1.13. Camchain and tensioner - C90 model



- 1 Camshaft sprocket
- 2 Camchain
- 3 Tensioner assembly
- 4 Spring
- 5 Pushrod
- 6 Pushrod insert
- 7 Rubber pad
- 8 Adjusting screw assembly
- 9 Retaining plate
- 10 Retaining plate (2 off)
- 11 Guide roller
- 12 Pivot bolt
- 13 Adjusting screw
- 14 Guide rod
- 15 Collar (2 off)
- 16 Oil pump sprocket
- 17 Sealing plug
- 18 Sealing washer
- 19 Washer
- 20 O-ring
- 21 Bolt (2 off)
- 22 Screw (3 off)




Fig. 1.14. Camchain and tensioner - C50 and C70 models

- 1 Camshaft sprocket
- 2 Camchain
- 3 Tensioner arm
- 4 Jockey pulley
- 5 Pivot bolt
- 6 Spring
- 7 Spring
- 8 Spring
- 9 Pushrod
- 10 Pushrod
- 11 Adjusting stud
- 12 Adjusting screw
- 13 Pushrod insert
- 14 Pushrod insert
- 15 Guide roller
- 16 Pivot bolt
- 17 Sprocket
- 18 Oil pump drive
- 19 Sealing plug
- 20 Sealing plug
- 21 Bolt (3 off)
- 22 Sealing washer
- 23 Washer
- 24 O-ring
- 25 Nut

as they are rotated, replacement is necessary. To remove the main bearings, if the appropriate service tool is not available, insert two thin steel wedges, one on each side of the bearing, and with these clamped in a vice hit the end of the crankshaft squarely with a rawhide mallet in an attempt to drive the crankshaft through the bearing. When the bearing has moved the initial amount, it should be possible to insert a conventional two or three legged sprocket puller, to complete the drawing-off action.

5 Note that the bottom camshaft chain sprocket must be withdrawn from the left-hand crankshaft before access can be gained to the main bearing. The sprocket is recessed to accommodate a puller.

6 The small end eye should also be checked for wear as the gudgeon pin should be a good fit. The piston should pivot on the gudgeon pin rather than the gudgeon pin rotate in the connecting rod.

#### 28 Cylinder barrel: examination and renovation

1 The usual indications of a badly worn cylinder barrel and piston are excessive oil consumption and piston slap, a metallic rattle that occurs when there is little or no load on the engine. If the top of the bore of the cylinder barrel is examined carefully, it will be found that there is a ridge on the thrust side, the depth of which will vary according to the amount of wear that has taken place. This marks the limit of travel of the uppermost piston ring.

2 Measure the bore diameter just below the ridge, using an internal micrometer. Compare this reading with the diameter at the bottom of the cylinder bore, which has not been subject to wear. If the difference in readings exceeds 0.005 inch it is necessary to have the cylinder rebored and to fit an oversize piston and rings.

3 If an internal micrometer is not available, the amount of cylinder bore wear can be measured by inserting the piston without rings so that it is approximately  $\frac{1}{8}$  inch from the top of the bore. If it is possible to insert 0.004 inch feeler gauge between the piston and the cylinder wall on the thrust side of the piston, remedial action must be taken.

4 Check the surface of the cylinder bore for score marks or any other damage that may have resulted from an earlier engine seizure or displacement of the gudgeon pin. A rebore will be necessary to remove any deep indentations, irrespective of the amount of bore wear, otherwise a compression leak will occur.

5 Check that the external cooling fins are not clogged with oil or road dirt; otherwise the engine will overheat. When clean, a coating of matt cylinder black will help improve the heat radiation.

#### 29 Piston and piston rings: examination and renovation

1 If a rebore is necessary, the existing piston and rings can be disregarded because they will be replaced with their oversize equivalents as a matter of course.

2 Remove all traces of carbon from the piston crown, using a soft scraper to ensure the surface is not marked. Finish off by polishing the crown, with metal polish, so that carbon does not adhere so easily in the future. Never use emery cloth.

3 Piston wear usually occurs at the skirt or lower end of the piston and takes the form of vertical streaks or score marks on the thrust side. There may also be some variation in the thickness of the skirt.

4 The piston ring grooves may also become enlarged in use, allowing the piston rings to have greater side float. If the clearance exceeds 0.004 inch for the two compression rings, or 0.005 inch for the oil control ring, the piston is due for replacement. It is unusual for this amount of wear to occur on its own.

5 Piston ring wear is measured by removing the rings from the piston and inserting them in the cylinder bore using the crown of the piston to locate them approximately  $1\frac{1}{2}$  inches from the top of the bore. Make sure they rest square with the bore. Measure

the end gap with a feeler gauge; if the gap exceeds 0.010 inch they require replacement, assuming the cylinder barrel is not in need of a rebore.

#### 30 Valves, valve seats and valve guides: examination and renovation

1 After cleaning the valves to remove all traces of carbon, examine the heads for signs of pitting and burning. Examine also the valve seats in the cylinder head. The exhaust valve and its seat will probably require the most attention because these are the hotter running of the two. If the pitting is slight, the marks can be removed by grinding the seats and valves together using fine valve grinding compound.

2 Valve grinding is a simple task, carried out as follows. Smear a trace of fine valve grinding compound (carborundum paste) on the seat face and apply a suction grinding tool to the head of the valve. With a semi-rotary motion, grind in the valve head to its seat, using a backward and forward action. It is advisable to lift the valve occasionally, to distribute the grinding compound evenly. Repeat this operation until an unbroken ring of light grey matt finish is obtained on both valve and seat. This denotes the grinding operation is complete. Before passing to the next operation, make quite sure that all traces of the grinding compound have been removed from both the valve and its seat and that none has entered the valve guide. If this precaution is not observed, rapid wear will take place, due to the abrasive nature of the carborundum base.

3 When deeper pit marks are encountered, it will be necessary to use a valve refacing machine and also a valve seat cutter, set to an angle of  $45^\circ$ . Never resort to excessive grinding because this will only pocket the valve and lead to reduced engine efficiency. If there is any doubt about the condition of a valve, fit a new replacement.

4 Examine the condition of the valve collars and the groove on the valve in which they seat. If there is any sign of damage, new replacements should be fitted. If the collars work loose whilst the engine is running, a valve will drop in and cause extensive damage.

5 Measure the valve stems for wear, making reference to the tolerance values given in the Specifications section of this Chapter. Check also the valve guides, which can be removed by heating the cylinder head in an oven then using a two diameter drift to drive them out of position. The initial diameter of the drift must be a good fit in the valve guide stem. Replace with the new valve guides whilst the cylinder head is still warm.

6 Check the free length of the valve springs against the list of tolerance in the Specifications. If the springs are reduced in length or if there is any doubt about their condition, they should be replaced.

#### 31 Cylinder head: decarbonisation and examination

1 Remove all traces of carbon from the cylinder head and valve ports, using a soft scraper. Extreme care should be taken to ensure the combustion chamber and valve seats are not marked in any way, otherwise hot spots and leakages may occur. Finish by polishing the combustion chamber so that carbon does not adhere so easily in the future. Use metal polish and NOT emery cloth.

2 Check to make sure that valve guides are free from carbon or any other foreign matter that may cause the valves to stick.

3 Make sure the cylinder head fins are not clogged with oil or road dirt, otherwise the engine will overheat. If necessary, use a wire brush.

#### 32 Camshaft, rockers and rocker shafts: examination

1 The cams should have a smooth surface and be free from scuff marks or indentations. It is unlikely that severe wear will be

encountered during the normal service life of the machine unless the lubrication system has failed or the case hardened surface has broken through.

- 2 Check the oil grooves on the end of the camshaft to ensure it is clean and free from sludge.
- 3 The internal oilways in the camshaft should also be cleaned and blown through to remove any obstruction.
- 4 It is unlikely that excessive wear will occur in the rocker arms and rocker shafts, but if it does it will be for the same reasons. A clicking noise from the rocker box is the usual symptom of wear in the rocker components, which should not be confused with the noise that results from excessive tappet clearance. If any shake is present and the rocker arm is loose on its shaft, a new rocker and/or shaft should be fitted.
- 5 Check the tip of the rocker arm at the point where it bears on the camshaft. If signs of cracking, scuffing or breakthrough are found in the case hardened surface, fit a new replacement. Check also the condition of the thread on the tappet, the rocker arm and the locknut.

### 33 Camshaft chain tensioner and sprockets: examination

- 1 An oil damped camshaft chain tensioner is employed, to fulfill the dual function of controlling the chain tension at high engine speeds and eliminating mechanical noise. A compression spring and pushrod within a guide provides the tension by bearing on one end of a pivoting arm which carries a jockey pulley on the other. The jockey pulley engages with the top run of the chain. The guide containing the spring and pushrod floods with oil when the engine is running, to provide the necessary damping medium.
- 2 The chain tensioner spring should have a free length of 3.04 inches. It should be replaced if the free length is reduced below 2.89 inches. To gain access to the spring and pushrod assembly, remove the 14 mm bolt that screws at an angle into the base of the left-hand crankcase.
- 3 Adjustment of the tensioner is automatic. Check that the tensioner is operating correctly when the left-hand flywheel generator cover and flywheel generator are removed.
- 4 The camshaft is of the endless variety and should not contain a split link.
- 5 It is unlikely that the camchain sprockets will need renewing unless the teeth have been damaged or broken.
- 6 Clean the sprockets so that any timing marks are easily identified.
- 7 It should be noted that later models may have a manual type of tensioner. Refer to the Routine Maintenance Chapter for information on how to recognise and adjust this type of tensioner.

### 34 Gearchange mechanism: examination

- 1 Examine the mechanism for any signs of damage, renewing any of the springs which may have become weak or broken.
- 2 Check for wear on the gearchange lever pawls as this can cause missed gearchanges.

### 35 Kickstart assembly: examination


- 1 Give the kickstart assembly a close visual inspection for signs of wear or damage such as broken or chipped teeth, removing the necessary circlips if dismantling for renewal of any parts.
- 2 Examine the kickstart return spring for weakness or damage. This component is often overlooked, even though it is tensioned every time the kickstart is depressed. It is best to renew as a precaution during a major overhaul, to prevent a further strippedown later.

### 36 Primary drive gears: examination


Both primary drive gears should be examined closely to ensure that there is no damage to the teeth. The depth of mesh is predetermined by the bearing locations and cannot be adjusted.

### 37 Gear selector drum and gear cluster: examination

- 1 This group of components was removed from the crankshaft as a unit, with care being taken to avoid losing any shims or washers from the ends of the shafts. The parts fall naturally into three sub-assemblies; the selector drum, the mainshaft and the layshaft.
- 2 The selector drum sub-assembly should be examined to ensure that the selector forks will slide easily on the drum without too much play. Check that the selector forks are not bent or excessively worn. To renew either selector fork, remove the spring clip and the cam track follower and slide the selector fork clear. When reassembling, ensure that the selector fork is fitted the right way round.
- 3 The mainshaft and layshaft sub-assemblies should be examined closely for any signs of wear or damage such as




33.6 Check the sprocket for worn or broken teeth




35.1 Check the condition of the ratchet spring




37.1 Note the relative positions before dismantling the gearbox components




37.2 Check the selector forks for wear or damage:



37.3a Check for wear on the layshaft components ...



37.3b ... and the mainshaft components ...



37.3c ... and ensure the O-rings are properly seated on reassembly

broken or chipped teeth, worn dogs and damaged or worn splines. Renew any parts found unserviceable as they cannot be reclaimed. To renew any parts, removal of the clips, washers and gears until the defective part is reached is straightforward and if the parts are laid out in sequence, reassembly should present no problems.

### 38 Engine reassembly: general

- 1 Before reassembly is commenced, the various engine and gearbox components should be thoroughly clean and placed close to the working area.
- 2 Make sure all traces of the old gaskets have been removed and the mating surfaces are clean and undamaged. One of the best ways to remove old gasket cement is to apply a rag soaked in methylated spirit. This acts as a solvent and will ensure the cement is removed without resort to scraping and the consequent risk of damage.
- 3 Gather together all the necessary tools and have available an oil can filled with clean engine oil. Make sure all the new gaskets and oil seals are to hand; nothing is more frustrating than having to stop in the middle of a reassembly sequence because a vital gasket or replacement has been overlooked.



4. Make sure the reassembly area is clean and that there is adequate working space. Refer to the torque and clearance settings wherever they are given. Many of the smaller bolts are easily sheared if they are over-tightened. Always use the correct size screwdriver bit for the crosshead screws and never an ordinary screwdriver or punch.

#### 39 Engine reassembly: fitting the bearings and oil seals to the crankcases and clutch cover

1. Before fitting any of the crankcase bearings make sure that the bearing housings are scrupulously clean and that there are no burrs or lips on the entry to the housings. Press or drive the bearings into the cases using a mandrel and hammer, after first making sure that they are lined up squarely. Warming the crankcases will help when a bearing is a particularly tight fit.
2. When the bearings have been driven home, lightly oil them and make sure they revolve smoothly. This is particularly important in the case of the main bearings.
3. Using a soft mandrel, drive the oil seals into their respective housings. Do not use more force than is necessary because the seals damage very easily.
4. Lightly oil all the other moving parts as a prelude to re-assembly. This will ensure all working parts are lubricated adequately during the initial start-up of the rebuilt engine.

#### 40 Engine reassembly: refitting the oil pump

1. Reference to Chapter 3 will fully explain the operation and renovation of the oil pump so that it is ready to fit to the crankcase as a sub-assembly.
2. Smear a very thin film of jointing compound such as Golden Hermatite onto the crankcase face and stick the gasket in position. Do not use an excessive amount of jointing compound as serious engine damage can result if any of the oilways are blocked.
3. Fit the oil pump in position and secure it with three screws. Check that it is free to rotate.

#### 41 Engine reassembly: refitting the camchain tensioner pulley and oil pump drive


1. On the CS0 and C70 models, fit the tensioner arm and its shouldered pivot bolt.
2. On the CS0 model, fit the tensioner ring and secure it in position with the three retaining plates and bolts.
3. Feed the oil pump drive sprocket into the crankcase ensuring that it fits the right way round, and screw in the drive shaft. Hold the sprocket securely and fully tighten the shaft.

#### 42 Engine reassembly: refitting the neutral indicator switch


1. Ensure that the sealing 'O' ring on the neutral indicator switch is in good condition before pushing the switch into the crankcase.
2. Fit the switch retaining plate and screw.

#### 43 Engine reassembly: replacing the gear selector drum and cluster


1. Place the left-hand crankcase on wooden blocks or an engine stand so that the inner side faces upwards.
2. Engage the selector forks in their respective positions, with the sliding dog on the layshaft and second gear on the mainshaft.
3. Remove the lower end of the two selector forks engages with the sliding dog on the layshaft and the upper fork with the second gear pinion on the mainshaft.



41.1 Refit the tensioner arm and pivot bolt




41.3 Ensure that the sprocket is the right way round




42.1 Check that the O-ring is in good condition






43.3a Reassemble the gearbox cluster ...



43.3b ... and retain the selector drum with this bolt



45.1 Refit the crankshaft assembly


3 Holding the complete gear assembly in the right-hand, locate the layshaft in the journal ball bearing, the mainshaft in the pilot bush and the tapered end of the selector drum in its housing. The 10 mm bolt and washer that hold the selector drum can then be fitted into the underside of the crankcase half. Tighten this bolt and later fit the rubber blanking plug.

#### 44 Engine reassembly: replacing the kickstart shaft assembly


- 1 The kickstart shaft will feed into the crankcase half but on the C90 model the kickstart return spring will need retensioning before the shaft will seat home properly.
- 2 Ensure that the kickstart friction spring is properly located in the crankcase half.

#### 45 Engine reassembly: replacing the crankshaft assembly

- 1 Fit the crankshaft assembly in the left-hand crankcase with the splined mainshaft uppermost. Make sure the connecting rod clears the aperture for the cylinder barrel spigot. It may be



44.2 Refit the kickstart shaft with ratchet spring in cast groove



46.3 Refit the crankcase half and ensure all the shafts still rotate

necessary to tap the assembly into position, if the crankshaft journal ball bearing is a tight fit in the steel outer ring.

#### 46 Engine reassembly: rejoining the crankcases

- 1 Smear the joint face with Golden Hermalite or other jointing compound and stick the gasket to the crankcase joint.
- 2 Ensure that the crankcase dowels are in position.
- 3 Lower the other crankcase half into position. Gentle tapping may be required to fit the two halves together as the bearings and dowels are a tight fit.
- 4 Rotate all the shafts to ensure that they will turn and that no binding occurs, especially the oil pump drive shaft, to ensure that the slot engages with the oil pump.
- 5 Excessive force should not be used as this shows something has been wrongly assembled or is out of alignment.
- 6 Replace the eight screws which hold the crankcase together.

#### 47 Engine reassembly: refitting the final drive sprocket


- 1 Now is an ideal time to fit the rubber blanking plug over the end of the gear selector drum.
- 2 The sprocket is pushed on the splines followed by the locking plate. The locking plate is turned in the groove and the two bolts tightened to clamp the plate to the sprocket.

#### 48 Engine reassembly: replacing and tensioning the kickstart return spring (C50 and C70 models only)


- 1 Rotate the kickstart shaft clockwise until it will go no further.
- 2 Fit the spring and retainer onto the shaft and engage the splines by gently easing the shaft anti-clockwise to ensure that the spring retainer hits the return stop.
- 3 Wind the kickstart return spring round until it hooks into the crankcase. Refit the retaining circlip.

#### 49 Engine reassembly: refitting the gearchange mechanism


- 1 Check the condition of the pawl spring and the return spring on the gearchange shaft assembly before assembling it into the crankcase.




47.1 Refit the rubber plug




47.2a Refit the sprocket ...




47.2b ... relocate the retaining plate ...




47.2c ... and tighten the two bolts



48.3 Replace the circlip to hold the spring retainer



49.1 Ensure the return spring fits round the spring stop



49.3a Refit the four pins ...

- 2 Grease the oil seal and carefully feed the gearchange shaft into position, ensuring that the splines do not damage the oil seal. An alternative method is to fit a small plastic bag over the shaft for feeding through the oil seal.
- 3 Refit the four small pins and the index plate onto the end of the gearchange drum, noting that the index plate is seated properly in the correct position.
- 4 Check the condition of the index arm spring and then refit the index arm with the shouldered bolt.

#### 50 Engine reassembly: reassembling the clutch and primary drive


- 1 The large primary drive pinion is fitted on the splines of the mainshaft and retained with a circlip.
- 2 Fit the double diameter spacer, the pinion bearing and the small drive pinion onto the crankshaft.
- 3 Reference to Chapter 2 will fully explain the operation and renovation of the clutch, so that it is ready to fit the crankshaft as a sub-assembly.
- 4 Fit the clutch sub-assembly, the tab washer and the special nut to the crankshaft.
- 5 Hold the clutch securely and tighten the sleeve nut to a torque of 27.5 to 32.5 ft lb as recommended in the Specifications section of this Chapter. Prise the tab washer into one of the slots in the sleeve nut.

#### 51 Engine reassembly: replacing the oil filters


- 1 Smear a thin film of jointing compound such as Golden Marmite on the outer face of the clutch and stick the gasket into position.
- 2 Refit the clutch outer plate to form the centrifugal filter and retain it with two screws (on the C90 model) or three screws (C50 and C70 models).
- 3 Check that the orifice in the clutch camplate is clean and the pressure relief spring is in good condition.
- 4 Fit the orifice and spring into the camplate and fit the camplate into the clutch outer plate.
- 5 Position the anti-rattle spring and locate the ball bearing carrier onto the spring.
- 6 Refit the clutch operating arm onto its splines, ensuring that the arm points towards the centre of the clutch. The C50 model has an additional washer fitted on the shaft.




49.3b ... and retain them with the index plate




49.4 Refit the index arm and pivot bolt




50.1 Retain the gear with the circlip




50.2a Refit the double diameter spacer and the bush ...



50.2b ... and slide the gear pinion into position



50.4 Ensure the clutch is properly located on its splines and the primary drive pinion



50.5 Prise the tab washer into one of the slots when the nut is fully tightened







51.4 Refit the camplate and oil orifice




51.5 Fit the spring and the ball retainer




51.6 Refit the operating arm



51.7 Slide the filter gauze into its slot



52.2a Reassemble the valve ...



52.2b ... the oil seal ...




- 7 Slide the clean filter gauze each into its slot in the bottom of the crankcase.
- 8 Smear the joint face with Golden Hermatite or other jointing compound and stick the gasket to the crankcase. Ensure that the two dowels are fitted correctly.
- 9 Slacken the clutch adjustment stud and locknut and lower the clutch cover into position, ensuring that the ball bearing carrier is not disturbed.
- 10 Gentle tapping may be required to ensure that the cover is fully home on the dowels. Care should be taken to ensure that the oil seal on the kickstart shaft is not damaged.
- 11 Replace the eight screws (on the C50 and C70 models) or nine screws (C90 model) which hold the cover but do not fully tighten the screw that carries the spark plug lead clip.
- 12 Readjust the clutch release mechanism and tighten the locknut as described in Chapter 2.6.
- 13 The kickstart lever and bolt can be replaced at this stage, but it is customary to refit these components once the engine is in the frame.

#### 52 Engine reassembly: replacing the valves and valve guides


- 1 When reassembling the valve guides into the cylinder head use a drift that fits the guide, such as the Honda service tool or use a long bolt and spacers and draw the guide into the head. It is possible to fractionally close the bore of a valve guide with hammering so that a valve will not slide freely - even though new parts have been used. Do not forget the 'O' ring seal.
- 2 The valve is fitted into the guide. The oil seal, oil seal cover and bottom spring register are fitted to the exhaust valve only, then the inner and outer valve springs and the spring register are clamped with a small valve spring compressor and the two half collets fitted. When removing the compressor ensure that the half collets are seating correctly.
- 3 The above procedure applies to both valves. The exhaust valve guide oil seal should be checked for damage if the engine has an oily exhaust.

#### 53 Engine reassembly: replacing the camshaft and rocker arms


- 1 The camshaft of the C50 and C70 models slides into the cylinder head once the cam lobes are lined up with the cutouts in the cylinder head. The C90 model camshaft is fitted after the cylinder head is attached to the engine.




52.2c ... the oil seal cap ...




52.2d ... the inner and outer valve springs ...



52.2e ... the spring register ...



52.2f ... and retain it all with two collets



53.1 Line up the cam lobes with the outaways in the head




53.2a Reposition the rocker arms ...


- 2 Slacken the tappet adjusting screws, position each rocker arm and slide the rocker pin into place, ensuring that the extraction thread is outermost.
- 3 On the C50 and C70 models the tappet adjustment can be made now but the operation is described later in this Chapter, when the engine is in the frame.

#### 54 Engine reassembly: refitting the piston and cylinder barrel


- 1 Raise the connecting rod to its highest point and pad the mouth of the crankcase with clean rag as a precaution against displaced parts falling into the crankcase.
- 2 Assemble the piston on the connecting rod, with the arrow on the piston crown facing downwards.
- 3 Lightly oil and fit the piston onto the connecting rod by inserting the gudgeon pin. Replace the circlips that retain the gudgeon pin making doubly sure that they are correctly seated in their grooves. Always renew the circlips as it is false economy to re-use the originals.
- 4 Thread the cam chain into position and ensure it seats properly onto the sprockets. Check that the two dowels are



53.2b ... and slide the rocker pins into position



54.2 Refit the piston ensuring circlips are seated correctly



54.4 Thread the camshaft chain into position

properly located on the holding down studs.

5 The cylinder base gasket should be stuck in position with Golden Marmite or other jointing compound, and the oil seal for the oil hole pushed into position.


6 The cylinder barrel should be fed onto the holding down studs. A piece of wire can be used to hook the cam chain through the cam chain tunnel.

7 The barrel should be lightly oiled and pushed further down the studs until the piston starts to enter the bore. The piston rings can then be compressed and fed into the bore.

8 When all three piston rings are in the bore the padding in the crankcase can be removed and the barrel slid down the studs to locate with the two dowels.

9 On the C60 and C70 models the cylinder barrel is retained in position by fitting the bolt on the left-hand side of the engine, finger tight.

10 Refit the guide roller into the camchain tunnel and retain it with the bearing bolt.



54.6 Slide the cylinder barrel down the studs

#### 55 Engine reassembly: replacing the cylinder head and timing the valves (C50 and C70 models only)

1 Before the cylinder head can be fitted to the engine it must be fully assembled. Although it may appear possible to replace the rockers when the cylinder head is bolted down, this is not so in practice. The rocker spindles are retained by the long holding down studs that pass through the cylinder head and cannot be removed or replaced unless the cylinder head is lifted.


2 Refit the dowels on the holding down studs and fit a new cylinder head gasket and its associated 'O' ring for sealing the oil passageways.

3 To ease later assembly, ensure that the piston is at top dead centre (TDC) and the camshaft is also positioned such that the cam lobes point downward, the corresponding position to top dead centre on the compression stroke. Fit the camshaft sprocket into the camchain so that the 'O' mark is positioned at the top.


4 Lower the cylinder head onto the studs and feed the camshaft sprocket into the camchain tunnel. Locate the cylinder head on the two dowels and push the sprocket onto the spigot on the end of the camshaft.

5 Fit the holding down bolt on the left-hand side of the engine, finger tight.


6 Check that the engine is still at top dead centre and with the lower run of the camchain taut, that the 'O' mark on the



54.10 Refit the guide roller in the barrel



55.3 Fit a new gasket and seals and the sprocket




55.4a Slide the cylinder head down the studs ...




55.4b ... and fit the sprocket onto the camshaft




55.6a Line up the 'T' mark with the crankcase mark ...




55.6b ... and the 'O' mark with the cylinder head mark for correct valve timing



55.7a Reassemble the tensioner pushrod ...



55.7b ... and spring and refit the sealing plug



55.8a Refit the top cover ...



lines up with the notch on the cylinder head. The scribe should be in the correct position for the three bolts to retaining the sprocket.

Fit the camchain tensioner plunger and pressure spring into the case and fit the sealing plug, after ensuring that the tensioner is in good condition. Recheck the timing to ensure it is correct.

The top cover gasket should be stuck in position with Golden Seal or other jointing compound and the top finned cover fitted so that the arrow between the central fins points towards the exhaust valve.

Fit the nuts and washers ensuring that the domed nuts and sealing washers are fitted in their correct positions, and pull down evenly until the recommended torque settings are achieved (6.5 - 8.7 ft lb). Always tighten in a diagonal sequence, an essential requirement because an alloy cylinder head will distort easily. There is a separate bolt on the left-hand side of the head, just below the circular camshaft sprocket.

Below this, a bolt at the base of the cylinder barrel must be tightened, as they are only finger tight at present. Fit the side cover gaskets into position, again using Golden Seal or other jointing compound, and bolt the finned cover then the circular cover in place. Refit the spark plug.

#### Model only

Before the cylinder head can be fitted to the engine, the arms must be assembled. Although it may appear possible to fit the rockers when the cylinder head is bolted down, it is not so in practice. The rocker spindles are retained by the holding down studs that pass through the cylinder head and must be removed or replaced unless the cylinder head is lifted. Fit the dowels on the holding down studs and fit a new cylinder head gasket, oil feed seal and camchain tunnel seal. Before later assembling, ensure that the piston is at top dead centre (TDC) and fit the camshaft sprocket into the camchain that the 'O' mark is positioned at the top.

Slide the cylinder head onto the studs and feed the camshaft sprocket into the camchain tunnel. Locate the cylinder head on the two dowels.

Slide the camshaft into the cylinder head through the oil feed and line the dowel pin up with 'O' mark, which should be in line with the notch on the cylinder head. Fit and tighten the two bolts securing the sprocket to the camshaft.

Fit the camchain tensioner plunger and pressure spring into the case and fit the sealing plug, after ensuring that the

sealing washer is in good condition. Recheck the timing to ensure that it is correct.

17 The top cover gasket should be stuck in position with Golden Seal or other jointing compound and the top finned cover fitted so that the arrow between the central fins points towards the exhaust valve.

18 Fit the nuts and washers, ensuring that the domed nuts and sealing washers are fitted in their correct positions, and pull down evenly until the recommended torque settings are achieved (6.5 - 8.7 ft lb). Always tighten in a diagonal sequence, an essential requirement because an alloy cylinder head will distort easily.

19 Fully tighten the camshaft bolts.

20 Stick the side gaskets into position, again using Golden Seal or other jointing compound, and bolt first the finned side cover then fix the contact breaker base into place with three screws. Ensure that the oil seal in the base is in good condition and undamaged.

21 Refit the dowel pin and the automatic advance mechanism and replace the bolt in the centre of the camshaft. Check the condition of the springs and the smooth action of the advance mechanism, renovating if necessary.

22 Refit the contact breaker assembly complete with the back plate and retain it with two screws, lining up with the scribe marks made inside during the dismantling stage. Reconnect the lead wire. If the contact breaker needs adjusting refer to Chapter 4 for full details. Always check the ignition timing, even if the scribe marks made earlier are in alignment with one another.

23 Stick the cover gasket into position again using Golden Seal or other jointing compound and refit the cover and two screws. Refit the spark plug.

#### 56 Engine reassembly: adjusting the tappets


1 The tappets should be adjusted to 0.002 inch clearance when the engine is cold and the piston is at top dead centre (TDC) on the compression stroke.

2 To adjust the tappets, slacken the locknut at the end of the rocker arm and turn the square-ended adjuster until the clearance is correct, as measured by a feeler gauge. Hold the square-ended adjuster firmly when the locknut is tightened, otherwise it will move and the adjustment will be lost.

3 After completing the adjustment to both valves, refit and tighten the rocker box caps, using new 'O' ring seals. Use a spanner that is a good fit otherwise the caps will damage easily.



55.9 with the arrow pointing towards the exhaust valve



55.10 Refit the side covers



sprocket lines up with the notch on the cylinder head. The camshaft should be in the correct position for the three bolts to be fitted, retaining the sprocket.

7 Slide the camchain tensioner plunger and pressure spring into the crankcase and fit the sealing plug, after ensuring that the sealing washer is in good condition. Recheck the timing to ensure that it is correct.

8 The top cover gasket should be stuck in position with Golden Hermatite or other jointing compound and the top finned cover fitted, so that the arrow between the central fins points towards the exhaust valve.

9 Fit the nuts and washers ensuring that the domed nuts and sealing washers are fitted in their correct positions, and pull down evenly until the recommended torque settings are achieved (6.5 - 8.7 ft lb). Always tighten in a diagonal sequence, an essential requirement because an alloy cylinder head will distort easily. There is a separate bolt on the left-hand side of the cylinder head, just below the circular camshaft sprocket aperture, and below this, a bolt at the base of the cylinder barrel. Both must be tightened, as they are only finger tight at present.

10 Stick the side cover gaskets into position, again using Golden Hermatite, and bolt the finned cover then the circular cover into place. Refit the spark plug.

#### C90 model only

11 Before the cylinder head can be fitted to the engine, the rocker arms must be assembled. Although it may appear possible to replace the rockers when the cylinder head is bolted down, this is not so in practice. The rocker spindles are retained by the long holding down studs that pass through the cylinder head and cannot be removed or replaced unless the cylinder head is lifted.

12 Refit the dowels on the holding down studs and fit a new cylinder head gasket, oil feed seal and camchain tunnel seal.

13 To ease later assembling, ensure that the piston is at top dead centre (TDC) and fit the camshaft sprocket into the camchain so that the 'O' mark is positioned at the top.

14 Lower the cylinder head onto the studs and feed the camshaft sprocket into the camchain tunnel. Locate the cylinder head on the two dowels.

15 Feed the camshaft into the cylinder head through the sprocket and line the dowel pin up with 'O' mark, which should be in line with the notch on the cylinder head. Fit and finger tighten the two bolts securing the sprocket to the camshaft.

16 Slide the camchain tensioner plunger and pressure spring into the crankcase and fit the sealing plug, after ensuring that the

sealing washer is in good condition. Recheck the timing to ensure that it is correct.

17 The top cover gasket should be stuck in position with Golden Hermatite or other jointing compound and the top finned cover fitted so that the arrow between the central fins points towards the exhaust valve.

18 Fit the nuts and washers, ensuring that the domed nuts and sealing washers are fitted in their correct positions, and pull down evenly until the recommended torque settings are achieved (6.5 - 8.7 ft lb). Always tighten in a diagonal sequence, an essential requirement because an alloy cylinder head will distort easily.

19 Fully tighten the camshaft bolts.

20 Stick the side gaskets into position, again using Golden Hermatite, and bolt first the finned side cover then fix the contact breaker base into place with three screws. Ensure that the oil seal in the base is in good condition and undamaged.

21 Refit the dowel pin and the automatic advance mechanism and replace the bolt in the centre of the camshaft. Check the condition of the springs and the smooth action of the advance mechanism, renovating if necessary.

22 Refit the contact breaker assembly complete with the back plate and retain it with two screws, lining up with the scribe marks made inside during the dismantling stage. Reconnect the lead wire. If the contact breaker needs adjusting refer to Chapter 4 for full details. Always check the ignition timing, even if the scribe marks made earlier are in alignment with one another.

23 Stick the cover gasket into position again using Golden Hermatite and refit the cover and two screws. Refit the spark plug.

#### 56 Engine reassembly: adjusting the tappets


1 The tappets should be adjusted to 0.002 inch clearance when the engine is cold and the piston is at top dead centre (TDC) on the compression stroke.

2 To adjust the tappets, slacken the locknut at the end of the rocker arm and turn the square-ended adjuster until the clearance is correct, as measured by a feeler gauge. Hold the square-ended adjuster firmly when the locknut is tightened, otherwise it will move and the adjustment will be lost.


3 After completing the adjustment to both valves, refit and tighten the rocker box caps, using new 'O' ring seals. Use a spanner that is a good fit otherwise the caps will damage easily.



55.8b ... with the arrow pointing towards the exhaust valve




55.10 Refit the side covers



56.3 Refit the tappet covers



57.1 Check that all the seals are in good condition



57.8 Refit the rotor


### 57 Engine reassembly: replacing the flywheel generator

#### *C50 and C70 models only*

- 1 Fit the two small 'O' rings that seal the stator plate screws in their counterbores, and fit the Woodruff key into the crankshaft.
- 2 Ensure that the central oil seal and the large 'O' ring on the outside diameter of the stator plate are in good condition and undamaged before fitting the plate in position. Secure it with the two screws, aligning the scribe marks made when the stator plate was removed, and fit the rubber grommets on the wires into their respective cutouts.
- 3 Reconnect the green/red striped wire to the neutral indicator switch.
- 4 Before fitting the flywheel rotor, place a few drops of light oil on the felt wick which lubricates the contact breaker cam in the centre of the flywheel rotor.
- 5 It is advisable to check also whether the contact breaker points require attention at this stage, otherwise it will be necessary to withdraw the flywheel rotor again in order to gain access. Reference to Chapter 4, will show how the contact breaker points are renovated and adjusted.



57.2 Refit the stator plate



58.2 Fit the spring link with the closed end facing the direction of chain travel

- 6 Check the condition of the springs and the smooth action of the automatic advance mechanism, renovating if necessary.
- 7 Feed the rotor onto the crankshaft so that the slot lines up with the Woodruff key. The rotor may have to be turned to clear the heel of the contact breaker before it will slide fully home.
- 8 The washer and rotor nut can now be fitted and the nut fully tightened, to the specified torque of 23.9 - 27.5 ft lb.
- 9 Refit the flywheel cover and secure it with three screws only if the engine is in the frame. Check the ignition timing, to verify it is correct.

#### C90 model only


- 1 Fit the rotor and secure it with its bolt and washer, tightening the bolt to the specified torque of 23.9 - 27.5 ft lb.
- 2 Fit the stator coils and secure them with the two screws, and fit the rubber grommets on the wires into the cutouts.
- 3 Reconnect the green/red striped wire to the neutral indicator switch.
- 4 Ensure that the two dowels are fitted correctly and smear Golden Marmalite or other jointing compound onto the crankcase joint face. Stick the gasket in position and fit the generator cover securing it with eight screws. Check the gearchange lever oil seal for any sign of deterioration or damage before fitting the cover.
- 5 Refit the sprocket cover and two screws if the engine is in the frame.
- 6 If the inspection cover has been removed, stick the gasket in position, again using Golden Marmalite, refit the cover and retain with the three screws. The condition of the 'O' rings on the three screws should be checked for any sign of deterioration or damage.

#### 58 Refitting the engine/gearbox unit in the frame

- 1 Follow in reverse the procedure given in Section 5 of this Chapter with the following points borne in mind:
- 2 Check that the final drive chain link is fitted the correct way round. The closed end of the spring link should lead as the chain rotates.
- 3 Ensure that a new copper/asbestos joint ring is used in the exhaust port as a leakproof joint is essential for the correct running of the engine.
- 4 Ensure that the sealing washer of the drain plug is in good condition and fully tighten the drain plug. Refill the engine unit with oil of the recommended viscosity, to the correct level.

#### 59 Starting and running the rebuilt engine

When the initial start-up is made, run the engine gently for the first few minutes in order to allow the oil to circulate throughout all parts of the engine. If the camshaft chain tensioner fitted is of a manual type, the tensioner should be adjusted in accordance with the instructions given in the Routine Maintenance Chapter. Remember that if a number of new parts have been fitted or if the engine has been rebored, it will be necessary to follow the original running-in instructions so that the new parts have ample opportunity to bed-down in a satisfactory manner. Check for oil leaks and/or blowing gaskets before the machine is run on the road.



58.3 Always use a new gasket for a leaktight joint



58.4 Refill the engine with the correct oil

#### 60 Fault diagnosis: engine

Symptom	Cause	Remedy
Engine does not start	Lack of compression	
	Valve stuck open	Adjust tappet clearance.
	Worn valve guides	Renew.
	Valve timing incorrect	Check and adjust.
	Worn piston rings	Renew.
	Worn cylinder	Rebore.
	No spark at plug	
	Fouled or wet spark plug	Clean.
	Fouled contact breaker points	Clean.
	Incorrect ignition timing	Check and adjust.
	Open or short circuit in ignition	Check wiring and cut-out switch.

	No fuel flowing to carburettor Blocked fuel tank cap vent hole Blocked fuel tap Faulty carburettor float valve Blocked fuel pipe	Clean. Clean. Renew. Clean.
Engine stalls whilst running	Fouled spark plug or contact breaker points Ignition timing incorrect Blocked fuel line or carburettor jets	Clean. Adjust. Clean.
Noisy engine	Tappet noise: Excessive tappet clearance Weakened or broken valve spring Knocking noise from cylinder: Worn piston and cylinder noise Carbon in combustion chamber Worn gudgeon pin or connecting rod small end Cam chain noise Stretched cam chain (rattle) Worn cam sprocket or timing sprocket	Check and reset. Renew springs.  Rebore cylinder and fit oversize piston. Decoke engine. Renew.  Adjust. Renew chain. Renew sprockets.
Engine noise	Excessive run-out of crankshaft Worn crankshaft bearings (rumble) Worn connecting rod or big end (knock) Worn transmission splines Worn or binding transmission gear teeth	Renew. Renew. Renew flywheel assembly. Renew. Renew gear pinions.
Smoking exhaust	Too much engine oil Worn cylinder and piston rings Worn valve guides Damaged cylinder	Check oil level and adjust as necessary. Rebore and fit oversize piston and rings. Renew. Renew cylinder barrel and piston.
Insufficient power	Valve stuck open or incorrect tappet adjustment Weak valve springs Valve timing incorrect Worn cylinder and piston rings Poor valve seatings Ignition timing incorrect Defective plug cap Dirty contact breaker points	Re-adjust. Renew. Check and reset. Rebore and fit oversize piston and rings. Grind in valves. Check and adjust. Fit replacement. Clean or renew.
Overheating	Accumulation of carbon on cylinder head Insufficient oil Faulty oil pump and/or blocked oil passage Ignition timing too far retarded	Decoke engine. Refill to specified level. Strip and clean. Re-adjust.

## 61 Fault diagnosis: gearbox

Symptom	Cause	Remedy
Difficulty in engaging gears	Broken centre gear selector pawl or cam Deformed gear selector	Renew. Repair or renew.
Machine jumps out of gear	Worn sliding gears on mainshaft and layshaft Distorted or worn gear selector fork Weak gearchange drum stop spring	Renew. Repair or renew. Renew spring
Gearchange lever fails to return normal position	Broken or displaced gearchange return spring	Renew or repair
Kickstart lever fails to return to normal position	Broken kickstart return spring	Renew spring.

## Chapter 2 Clutch

### Contents

General description	1	Clutch: reassembly	5
Clutch assembly: dismantling	2	Clutch: adjustment	6
Clutch: examination and renovation	3	Clutch: correct operation	7
Clutch operating mechanism: examination and renovation	4	Fault diagnosis: clutch	8

### Specifications

#### Clutch springs


Number	Four
Free length	19.6 mm (C50 model) 21.4 mm (C70 model) 27.0 mm (C90 model)
Minimum length	18.2 mm (C50 model) 20.4 mm (C70 model) 26.0 mm (C90 model)

#### Inserted clutch plates

Number	2 or 3, depending on model
Thickness	3.5 mm (C50 and C70 models) 2.9 mm (C90 model)
Minimum thickness	3.1 mm (C50 and C70 models) 2.4 mm (C90 model)

### 1 General description

The clutch is of the multi-plate type having two or three plain plates and two or three inserted plates depending on the model. The clutch is fully automatic in operation and inter-connected with the gear change pedal so that it disengages and re-engages in the correct sequence.



2.1a Remove the large circlip ...

### 2 Clutch assembly: dismantling

The clutch assembly complete is removed by following the procedure detailed in Chapter 1, Sections 12 and 13. When removed, the clutch can be broken down into its component parts as follows:

- 1 With the drive side (back) facing upwards, prise out the



2.1b ... lift out the clutch centre ...



	No fuel flowing to carburettor Blocked fuel tank cap vent hole Blocked fuel tap Faulty carburettor float valve Blocked fuel pipe	Clean. Clean. Renew. Clean.
Engine stalls whilst running	Fouled spark plug or contact breaker points Ignition timing incorrect Blocked fuel line or carburettor jets	Clean. Adjust. Clean.
Noisy engine	Tappet noise: Excessive tappet clearance Weakened or broken valve spring Knocking noise from cylinder: Worn piston and cylinder noise Carbon in combustion chamber Worn gudgeon pin or connecting rod small end Cam chain noise Stretched cam chain (rattle) Worn cam sprocket or timing sprocket	Check and reset. Renew springs.  Rebore cylinder and fit oversize piston. Decoke engine. Renew.  Adjust. Renew chain. Renew sprockets.
Engine noise	Excessive run-out of crankshaft Worn crankshaft bearings (rumble) Worn connecting rod or big end (knock) Worn transmission splines Worn or binding transmission gear teeth	Renew. Renew. Renew flywheel assembly. Renew. Renew gear pinions.
Smoking exhaust	Too much engine oil Worn cylinder and piston rings Worn valve guides Damaged cylinder	Check oil level and adjust as necessary. Rebore and fit oversize piston and rings. Renew. Renew cylinder barrel and piston.
Insufficient power	Valve stuck open or incorrect tappets adjustment Weak valve springs Valve timing incorrect Worn cylinder and piston rings Poor valve seatings Ignition timing incorrect Defective plug cap Dirty contact breaker points	Re-adjust. Renew. Check and reset. Rebore and fit oversize piston and rings. Grind in valves. Check and adjust. Fit replacement. Clean or renew.
Overheating	Accumulation of carbon on cylinder head Insufficient oil Faulty oil pump and/or blocked oil passage Ignition timing too far retarded	Decoke engine. Refill to specified level. Strip and clean. Re-adjust.

## 61 Fault diagnosis: gearbox

Symptom	Cause	Remedy
Difficulty in engaging gears	Broken centre gear selector pawl or cam Deformed gear selector	Renew. Repair or renew.
Machine jumps out of gear	Worn sliding gears on mainshaft and layshaft Distorted or worn gear selector fork Weak gearchange drum stop spring	Renew. Repair or renew. Renew spring
Gearchange lever fails to return normal position	Broken or displaced gearchange return spring	Renew or repair
Kickstart lever fails to return to normal position	Broken kickstart return spring	Renew spring.




Fig. 2.1. Clutch assembly - C70 model

- |                      |                                  |                             |                   |
|----------------------|----------------------------------|-----------------------------|-------------------|
| 1 Clutch drum        | 10 Drive plate                   | 17 Ball bearing retainer    | 26 Washer         |
| 2 Outer cover        | 11 Clutch spring (4 off)         | 18 Circlip                  | 27 Washer (4 off) |
| 3 Outer cover gasket | 12 Clutch plate spring (4 off)   | 19 Driver gear              | 28 Circlip        |
| 4 Clutch centre      | 13 Clutch damping spring (4 off) | 20 Clutch centre inner gear | 29 Circlip        |
| 5 Bush               | 14 Clutch lever                  | 21 Primary drive gear       | 30 Roller (8 off) |
| 6 Friction plate     | 15 Cam plate                     | 22 Oil orifice              | 31 Screw (4 off)  |
| 7 Clutch plate       | 16 Spring                        | 23 Orifice spring           | 32 Screw (3 off)  |
| 8 Clutch plate       |                                  | 24 Special nut              | 33 Ball bearing   |
| 9 Clutch plate       |                                  | 25 Tab washer               |                   |






Fig. 2.2. Clutch assembly - C90 model


- |                      |                                  |                          |                   |
|----------------------|----------------------------------|--------------------------|-------------------|
| 1 Clutch drum        | 11 Clutch spring (4 off)         | 19 Cam plate             | 29 Orifice spring |
| 2 Outer cover        | 12 Clutch plate spring (6 off)   | 20 Spring                | 30 Special nut    |
| 3 Outer cover gasket | 13 Clutch damping spring (4 off) | 21 Adjustable cam plate  | 31 Tab washer     |
| 4 Clutch centre      | 14 Drive plate                   | 22 Adjuster              | 32 Circlip        |
| 5 Bush               | 15 Bob-weight (24 off)           | 23 Ball bearing retainer | 33 Washer (4 off) |
| 6 Friction plate     | 16 Bob-weight clip               | 24 Circlip               | 34 Screw (4 off)  |
| 7 Clutch plate       | 17 Bob-weight stop ring          | 25 Spacer                | 35 Screw (2 off)  |
| 8 Clutch plate       | 18 Clutch lever                  | 26 Drivegear             | 36 Circlip        |
| 9 Clutch plate       |                                  | 27 Primary drive gear    | 37 Ball bearing   |
| 10 Clutch plate      |                                  | 28 Oil orifice           |                   |




2.1c ... and remove the clutch plates



2.2 Remove the eight rollers which act as centrifugal weights



2.3 Remove the four screws to release the drive plate and springs



2.4 The circlip retains the clutch centre



3.4 Examine the clutch plates carefully

mm circlip from the rear of the clutch body and lift out the clutch centre assembly, complete with the clutch plates. The clutch plates will lift off the centre but care should be taken to avoid losing the four small plate separation springs that are located on the pins of the first clutch plate.

2 Remove the eight hardened steel rollers or on the CS0 model the four shaped weights and clip.

3 Invert the clutch body and remove the four crosshead screws from the front face, unscrewing each a little at a time. This will release the drive plate, the four small damper springs and the four main clutch springs.

4 Removal of the retaining circlip from the clutch centre will permit the clutch drive gear to be separated.

### 3 Clutch: examination and renovation

- 1 Check the condition of the clutch drive to ensure none of the teeth are chipped, broken or badly worn.
- 2 Give the plain and the inserted clutch plates a wash with a paraffin/petrol mix and check that they are not buckled or distorted. Remove all traces of clutch insert debris, otherwise a gradual build-up will affect clutch action.

3 Visual inspection will show whether the tongues of the clutch plates have become burred and whether indentations have formed in the slots with which they engage. Burrs should be removed with a file, which can also be used to dress the slots, provided the depth of the indentations is not great.

4 Check the thickness of the friction linings in the inserted plates, referring to the Specifications section of this Chapter for the serviceable limits. If the linings have worn to, or below these limits, the plates should be renewed. Worn linings promote clutch slip.

5 Check also the free length of the clutch springs. The recommended serviceable limits are also in the Specification section. Do not attempt to stretch the springs if they have compressed. They must be renewed when they reach the serviceable limit, as a complete set.

6 Check the condition of the roller thrust bearing in the clutch outer plate.

#### 4 Clutch operating mechanism: examination and renovation

The automatic clutch fitted to these models is designed so that as the engine speed increases, eight hardened steel rollers increase their pressure on the clutch plates through being thrown outwards along their respective tapered tracks by centrifugal force. Four small diameter compression springs assist the clutch plates to free, and four large diameter compression springs supply additional pressure when the rollers reach the end of their tracks.

A quick acting three-start thread mechanism is incorporated in an extension of the drive gear to apply pressure when the kickstart is operated, or when the machine is on the over-run.

The clutch is completely disengaged each time the gear operating pedal is moved, through a direct linkage between the gear change lever spindle and the clutch withdrawal mechanism.

1 Check the condition of the roller ramps in the clutch drive plate and the roller contact area. Excessive wear in these areas is often the cause of engine stalling, fierce clutch engagement and difficulty in gear changing. Replace the worn parts.

2 It is rarely necessary to replace the eight rollers or the clutch housing, unless the rollers show evidence of wear and the clutch housing has roller indentations. This type of wear is caused by poor gear changing, usually by releasing the gear pedal too fast when moving away from a standstill or changing gear.

3 The C90 model uses a different mode of operation involving the use of four weights. The earliest problem of wear is therefore obviated even though the clutch operates on the centrifugal

principle.

#### 5 Clutch: reassembly

1 Reassemble the clutch components by following the dismantling procedure in reverse.

2 The built-up clutch is then replaced on the splined end of the crankshaft, following the engine reassembly procedure given in Chapter 1, Section 50. A torque setting of 27.5 - 32.5 lbs ft is recommended for the sleeve nut that retains the clutch in position. Make sure the tab washer is bent over, to lock the sleeve nut in position.

3 Replace the oil filters and cover reassembly as described in Chapter 1, Section 51, ensuring that the clutch is adjusted according to the details given in the next section of this Chapter.

#### 6 Clutch: adjustment

1 Clutch adjustment is provided by means of an adjustable screw and locknut located in the centre of the clutch cover. Slacken off the 10 mm locknut and turn the adjusting screw firstly in the clockwise direction, to ensure there is no end pressure on the clutch pushrod.

2 Turn the adjusting screw anti-clockwise until pressure can be felt on the end. Turn back (clockwise) for approximately 1/8th of a turn, and tighten the locknut, making sure the screw does not turn. Clutch adjustment should now be correct.


#### 7 Clutch: correct operation

1 As the special starting mechanism operates when starting the engine, clutch slip can only be detected when the machine is being ridden, by the fact that the engine speed will increase with no increase in road speed.


2 Clutch drag is characterised by the engine having a tendency to stall or the machine starting to move forward, when first gear is engaged, with the engine running at tickover speed.

3 Refer to the fault diagnosis chart, Section 8, for possible causes for the above symptom.

4 Note that a fast tickover speed will cause the machine to snatch when first gear is engaged during the pullaway from a standstill.



3.6 Check the condition of the ball bearing



6.1 Clutch is adjusted with the cover attached



**8 Fault diagnosis: clutch**

Symptom	Cause	Remedy
Clutch slips	Incorrect adjustment Weak clutch springs Worn or distorted pressure plate Distorted clutch plates Worn friction plates	Re-adjust. Renew set of four. Renew. Renew. Renew.
Knocking noise from clutch	Loose clutch centre	Renew clutch.
Clutch does not fully disengage	Incorrect adjustment Uneven clutch spring tension Distorted clutch plates	Re-adjust Re-adjust. Renew.




Fig. 3.2. Carburettor assembly - C90 model

- 1 Complete carburettor gasket set
- 2 Float needle valve set
- 3 Needle and jet set
- 4 Float assembly
- 5 Slide top assembly
- 6 Float chamber assembly
- 7 Slow running and throttle stop screws
- 8 Slide and return spring
- 9 Carburettor assembly
- 10 Needle jet holder
- 11 Cable sleeve
- 12 Bolt
- 13 Screw (2 off)
- 14 Screw (2 off)
- 15 Screw (2 off)
- 16 Washer (2 off)
- 17 Breather tube
- 18 Overflow tube
- 19 Tube clip (2 off)
- 20 Main jet
- 21 Slow running jet

7 Remove the two blanking plugs that are close to the mounting flange and remove the main jet, using a small screwdriver, from the carburettor body.

8 Remove the float chamber drain screw.

9 The choke flap is rivetted into position and cannot easily be removed.

#### 9 Carburettor: dismantling (C90 model only)

1 At this stage, the carburettor is still attached to the control cable and to remove it completely, the carburettor top has to be unscrewed and the slide and needle pulled out.

2 Compress the slide return spring and unhook throttle cable. The slide, the needle with its spring clip, the w-shaped spring, the return spring and the carburettor top will then slide off the cable.

3 Remove the two screws holding the float chamber in position and pull the chamber clear. Remove the two screws on the end of the float chamber to release the blanking plate, sealing ring and petrol filter. Remove the float chamber drain screw.

4 Invert the carburettor body and push out the float pivot pin. This releases the float and the float needle. Carefully remove the float needle from the float.

5 Remove from the underside of the carburettor body the float needle seat, the slow running jet and from the centre the main jet, the jet holder and the needle jet.

6 Remove the throttle stop screw and the slow running air screw from the side of the carburettor, taking care not to lose the small springs.

7 The choke flap is rivetted into position and cannot easily be removed.

#### 10 Carburettor: cleaning, examining and reassembling


1 Thoroughly clean all the parts paying particular attention to the internal passageways of the carburettor body, the bottom of the float chamber and any other places where sediment may collect.

2 Check that none of the springs are weak or broken.


3 Check for wear on the slide and carburettor body as air leaks round the slide can cause weak mixture problems.

4 Check for ridges on the conical sealing portion of the float needle.


5 Check the condition of the float and shake it to see if there is




8.6c ... and the slow running jet from the one adjacent




8.7a Remove the two sealing plugs ...




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw




8.8 Remove the float chamber drain screw






10.5 Check the float assembly for damage



12.1 Clean the air filter carefully as it is only paper



13.2a Remove the swinging arm nut to release the silencer ...

any petrol inside. The float is non-repairable and should be renewed if damaged or punctured.

6 Check that all gaskets, sealing washers or rubber seals are in good condition. Preferably renew them when reassembling as leaking petrol can cause a fire.

7 When reassembling the carburettor, follow the dismantling instructions in reverse, ensuring that the needle clip is in its correct groove.

8 The various sizes of the jets, throttle slide and needle are predetermined by the manufacturer and should not require modification. Check with the Specifications list if there is any doubt about the values fitted.

### 11 Carburettor: adjustments

1 All adjustments should be made when the engine is at normal working temperature.

2 To adjust the slow running speed the throttle cable should be slackened to ensure that it is the throttle stop screw that is holding the slide and not the cable. Set the throttle stop screw so that the engine runs at a fast tick-over speed.

3 Screw in or out the air screw until the engine runs evenly, without hunting or misfiring. Reduce the engine speed by unscrewing the throttle stop and re-adjust the air screw, if necessary. Do not arrive at a setting where the engine ticks over too slowly, otherwise there is risk that it may stall when the throttle is closed, during normal running.

4 As a rough guide, the air screw should be positioned from one to one and a quarter complete turns out from the fully closed position.

5 The amount of throttle slide cutaway, size of main jet, size of needle jet and size of slow running jet are pre-determined by the manufacturer and should be correct for the model in which they are used. Check with the Specifications, page 67. The throttle needle position can be varied, by removing and replacing the needle clip. Under normal circumstances, the needle should be positioned in the second or third notch, measured from the top.

6 The slow running jet controls engine speed up to approximately 1/8th throttle and the degree of throttle slide cutaway from 1/8th to 1/2 throttle. Thereafter the needle jet takes over, up to 3/4 throttle, and main jet size controls the final 1/4 to full throttle. These stages are only approximate; there is a certain amount of overlap.

7 Readjust the throttle cable to remove any excess play but leave a small amount of slack to avoid the engine speed increasing when the handlebars are turned.



13.2b ... and the collets to release the exhaust pipe

12

1

imm

the

2

it lig

with

Rem

dam.

3

and r

4

reco

cond

repla

for th

5

elem

carbu

13

1

requi

never

to tin

back

neces

frequ

more

2

by del

the ex

collets

gasket

consec

seal, th

3

A

detach

the ba

cleanin

4

Tap

brush,

sludge,

deposi

5

Thi

amoun

3.3

Th

### 12 Air filter: location and cleaning

- 1 The air filter is located on top of the main frame tube, immediately behind the steering head. It is clearly visible when the the legshield assembly has been removed.
- 2 To clean the air filter, remove the detachable element and tap it lightly to remove accumulated dust. Blow from the inside with compressed air, or brush the exterior with a light brush. Remember the element is made from paper. If it is torn or damaged, fit a replacement.
- 3 Oil or water will reduce the efficiency of the filter element and may upset the carburation. Renew any suspect element.
- 4 It is advisable to replace the element at less than the recommended 6,000 miles if the machine is used in very dusty conditions. The usual signs of a filter element in need of replacement are reduced performance, misfiring and a tendency for the carburation to run rich.
- 5 On no account should the machine be run without the filter element in place because this will have an adverse effect on carburation.

### 13 Exhaust system: cleaning

- 1 Although the exhaust system on a four-stroke does not require such frequent attention as that of the two-stroke, it is nevertheless advisable to inspect the complete system from time to time in order to ensure a build-up of carbon does not cause back pressure. If an engine is nearing the stage where a rebore is necessary, it is advisable to check the exhaust system more frequently. The oily nature of the exhaust gases will cause a more rapid build-up of sludge.
- 2 The complete exhaust system is removed from the machine by detaching the swinging arm nut, the two nuts and flange at the exhaust port, and pulling the exhaust clear. The two half collets will fall clear from the exhaust pipe but the exhaust gasket will need to be prised out of the cylinder head and consequently will need renewing. If this joint is not an airtight seal, the engine will tend to backfire on the over-run.
- 3 A 10 mm bolt in the extreme end of the silencer retains the detachable baffle assembly in position. If this bolt is withdrawn, the baffle tube can be pulled clear of the silencer body, for cleaning.
- 4 Tap the baffle to remove loose carbon and work with a wire brush, if necessary. If there is a heavy build-up of carbon or oily sludge, it may be necessary to use a blow lamp to burn out these deposits.
- 5 The exhaust pipe and silencer are one unit and if a large amount of carbon has built up inside it is necessary to fill the

silencer with a solution of caustic soda after blocking up one end. If possible, leave the caustic soda solution within the silencer overnight, before draining off and washing out thoroughly with water.

6 Caustic soda is highly corrosive and every care should be taken when mixing and handling the solution. Keep the solution away from the skin and more particularly the eyes. The wearing of rubber gloves is advised whilst the solution is being mixed and used.

7 The solution is prepared by adding 3 lbs of caustic soda to 1 gallon of COLD water, whilst stirring. Add the caustic soda a little at a time and NEVER add the water to the chemical. The solution will become hot during the mixing process, which is why cold water must be used.

8 Make sure the used caustic soda solution is disposed of safely, preferably by diluting with a large amount of water. Do not allow the solution to come into contact with aluminium castings because it will react violently with this metal.


9 To reassemble the exhaust system reverse the dismantling procedure, ensuring that the baffle assembly retaining bolt is fully tightened.

10 Do not run the machine without the baffle tube in position. Although the changed engine note may give the illusion of greater speed, the net effect will be a marked drop in performance as a result of changes in carburation. There is also risk of prosecution as a result of the excessive noise.


### 14 Lubrication system

1 Oil is picked up from the oil compartment in the crankcase by the oil pump, via an oil filter screen which filters out any impurities that may otherwise damage the pump itself. The pump delivers oil, under pressure, to the right-hand crankcase where it follows the routes listed below:

- a) The oil passes through a drilling in the clutch cover, through the pressure release orifice in the centre of the clutch, through the centrifugal oil filter, and into the crankshaft, to lubricate the big end and main bearings.
- b) The oil passes up the side of one of the holding down studs, through the cylinder barrel and into the cylinder head, where a side cover distributes the oil to the rocker pins and the camshaft. Some of the oil lubricates the camchain on its return, although the C50 and C70 models have an oil return passageway.
- c) On the C90 model only, there are additional drillings within the crankcases to feed oil to the mainshaft and layshaft plain bearings.



13.3 The baffle tube is removable for cleaning



15.3 The gauze oil filter fits in a slot in the crankcase






Fig. 3.3. Clutch cover and oil pump - C70 model

- |                       |                        |                 |                   |
|-----------------------|------------------------|-----------------|-------------------|
| 1 Clutch cover        | 8 Inner rotor          | 15 Clip         | 21 Bolt           |
| 2 Clutch cover gasket | 9 Outer rotor          | 16 Washer       | 22 Screw (3 off)  |
| 3 Oil pump gasket     | 10 Driveshaft          | 17 Oil seal     | 23 Screw (6 off)  |
| 4 Oil pump assembly   | 11 Dowel               | 18 O-ring       | 24 Screw (2 off)  |
| 5 Oil pump body       | 12 Dipstick            | 19 O-ring       | 25 Nut            |
| 6 Oil pump cover      | 13 Adjustable camplate | 20 Bolt (2 off) | 26 Washer (3 off) |
| 7 Cover gasket        | 14 Adjuster            |                 |                   |

2 The remainder of the engine components are lubricated by splash from the oil content of the sump.

#### 15 Oil filters and pressure relief valve: location and cleaning

1 As explained in the previous Section, there are two filters in the lubrication system, a square section gauze filter screen that slots into a cavity in the right-hand crankcase, and a filter of the centrifugal type that is attached to the outer face of the clutch.

2 Both can be removed for cleaning when the procedure given in Chapter 1 Section 12 is followed.

3 The gauze filter should be cleaned by immersing it in petrol and if necessary, brushing it with a soft haired brush to remove any impurities or foreign matter. Allow it to dry before replacement. If for any reason the gauze is damaged, the complete filter must be renewed.

4 The centrifugal filter should be washed out with petrol and any impurities or foreign matter removed in similar fashion. Dry the assembly with clean rag, prior to reassembly. Before replacing the end cover and tightening the screws, check the condition of the sealing gasket.

5 When using petrol for washing purposes, take extreme care as petrol vapour is highly inflammable. Cleaning should preferably be accomplished in the open air or in well-ventilated surroundings away from any naked flames.


6 In the centre of the clutch release mechanism there is a spring loaded orifice that acts as a pressure relief valve. Ensure that the hole in the orifice is clear, that the spring is in good condition and that the orifice is free to move within the release mechanism.

7 For the reassembly sequence, refer to Chapter 1 Section 51.

#### 16 Trochoidal oil pump: description and location

1 The trochoid oil pump is located behind the clutch, where it is retained to the right-hand crankcase by three bolts. It is extremely unlikely that the pump will require attention under normal circumstances and should not be dismantled unnecessarily.


2 The pump comprises an inner and an outer rotor. The pumping action is provided by the differences in the shape and number of teeth between the inner and the outer rotors.




15.4 The clutch outer plate forms the centrifugal oil filter



15.6 Check the pressure relief valve



17.2 Remove the cover to check oil pump operation



17.5 Remove the pump to renew any worn parts

**17 Trochoidal oil pump: removal, renovation and replacement**

- 1 If the pump is suspected in the event of a lubrication failure, it can be dismantled after it has been detached from the engine unit by referring to Sections 12, 13 and 23 of Chapter 1.
- 2 Remove the three screws and the rotor cover plate to gain access to the inner and outer rotors.
- 3 Clearances between the various internal components

can be checked with the wear limits given in the Specifications Section of this Chapter.

- 4 To reassemble the oil pump, fit the outer rotor, the inner rotor and feed the drive shaft into position rotating the rotors if necessary to fully engage the shaft. Stick the cover gasket in position, using a film of grease, and refit the cover and screws.
- 5 Relit the oil pump as described in Chapter 1 Section 40 and complete the engine reassembly as described in Chapter 1 Sections 50 and 51.

**18 Fault diagnosis: fuel system and lubrication**

Symptom	Cause	Remedy
Excessive fuel consumption	Air cleaner choked or restricted Fuel leaking from carburettor. Float sticking  Badly worn or distorted carburettor Jet needle setting too high Main jet too large or loose Carburettor flooding	Clean or renew. Check all unions and gaskets. Float needle seat needs cleaning Renew. Adjust to figure given in Specifications. Fit correct jet or tighten if necessary. Check float valve and renew if worn.
Idling speed too high	Throttle stop screw in too far. Carburettor top loose Pilot jet incorrectly adjusted Throttle cable sticking	Adjust screw. Tighten top. Refer to relevant paragraph in this Chapter. Disconnect and lubricate or replace.
Engine dies after running a short while	Blocked air hole in filler cap Dirt or water in carburettor	Clean. Remove and clean out.
General lack of performance	Weak mixture; float needle stuck in seat Air leak at carburettor joint	Remove float chamber or float and clean. Check joint to eliminate leakage, and fit new O-ring.
Engine does not respond to throttle	Throttle cable sticking Petrol octane rating too low	See above. Use higher grade (star rating) petrol.
Engine runs hot and is noisy	Lubrication failure	Stop engine immediately and investigate cause. Slacken cylinder head nut to check oil circulation. Do not restart until cause is found and rectified.

# Chapter 4 Ignition system

## Contents

General description	1	replacement	6
Legshield: removal	2	Condenser: removal and replacement	7
Flywheel generators: checking output	3	Ignition timing: checking and re-setting	8
Ignition coil: checking, removal and replacement	4	Automatic advance unit: location and checking action	9
Contact breaker: adjustment	5	Spark plug: checking and resetting gap	10
Contact breaker assembly: removal, renovation and		Fault diagnosis: ignition system	11

## Specifications

	C50	C70	C90
<b>Generator</b>			
Make	Hitachi Seisakusho	Mitsubishi Denki or Nippon Denso	Kokusan Denki
Type	F120	FAZ or 37000-026-0	EG26
<b>Coil</b>			
Make	Hitachi Seisakusho	Hitachi Seisakusho	Kokusan Denki
Type	CM61 - 08	CM61 - 08	ST 78
<b>Spark plug</b>			
Make	NGK or Champion	NGK or Champion	NGK or Champion
Type	C - 7HS Z - 8 or Z - 10	C - 7HS Z - 8 or Z - 10	D - 6HS or P7
Gap	0.6 - 0.7 mm (0.024 - 0.028 inch)	0.6 - 0.7 mm (0.024 - 0.028 inch)	0.6 - 0.7 mm (0.024 - 0.028 inch)
<b>Contact breaker gap</b>	0.3 - 0.4 mm (0.012 - 0.016 inch)	0.3 - 0.4 mm (0.012 - 0.016 inch)	0.3 - 0.4 mm (0.012 - 0.016 inch)

### General description

The system used for producing the spark which is necessary to ignite the petrol/air mixture in the combustion chamber differs slightly between that used for the C50 and C70 models and the C90 model.

In the C50 and C70 system, the flywheel generator produces the electrical power which is fed directly to the ignition coil, mounted inside the frame. The condenser and contact breaker assembly are mounted inside the flywheel generator, where, with the help of an automatic advance and retard mechanism, they determine the exact moment at which the spark will occur. The ignition switch shorts out the ignition system when it is switched off.

In the C90 system, the battery produces the electrical power, which is fed through a fuse and the ignition switch to the ignition coil, mounted inside the frame. The condenser is mounted on the end of the ignition coil. The contact breaker assembly and automatic advance and retard mechanism are mounted on the end of the camshaft, on the left-hand side of the cylinder head. The generator will produce sufficient power for starting the engine if the battery is flat.

When the contact breaker points separate, the electrical

circuit is interrupted and a high tension voltage is developed across the points of the spark plug, which jumps the air gap and ignites the mixture.

### 2 Legshield: removal

1 The plastic legshield assembly encloses the engine unit to enhance the clean appearance of the machine. There are suitable holes and blanking discs to enable the simplest of the adjusting tasks to be carried out without removing the legshield, but whenever access is required for more complex tasks the legshield assembly must be removed.

2 Place the machine on the centre stand and make sure it is standing firmly on level ground.

3 Remove the side panels to obtain the toolkit and reveal the battery. Unscrew the fuse holder and remove the fuse to isolate the battery, eliminating all risks of electrical mishap.

4 Remove the domed nut and the air cleaner lid.

5 Slacken the nuts holding the rear of the legshield assembly and remove the clamping band if fitted. Remove the four bolts holding the legshields and pull their spacers clear. The legshields will now lift clear.




Fig. 4.1. Flywheel generator and cover - C70 model

- |                            |                   |
|----------------------------|-------------------|
| 1 Generator cover          | 16 Grammet        |
| 2 Contact breaker assembly | 17 Screw          |
| 3 Felt wick                | 18 Screw          |
| 4 Condenser                | 19 Washer         |
| 5 Inspection cover         | 20 Oil seal       |
| 6 Cover gasket             | 21 Oil seal       |
| 7 Ignition coil            | 22 O-ring         |
| 8 Generator assembly       | 23 O-ring (2 off) |
| 9 Generator assembly       | 24 Screw (2 off)  |
| 10 Rotor                   | 25 Screw          |
| 11 Stator plate assembly   | 26 Screw (2 off)  |
| 12 Stator plate assembly   | 27 Screw (2 off)  |
| 13 Lighting coil           | 28 Nut            |
| 14 Lighting coil           | 29 Washer         |
| 15 Grammet                 | 30 Washer (2 off) |



### 3 Flywheel generators: checking outputs

The output from either of the two types of generator used can be checked only with specialised test equipment of the multi-meter type. It is unlikely that the average owner/rider will have access to this equipment or instruction in its use. In consequence, if the performance of a generator is suspect, it should be checked by a Honda agent or an auto-electrical expert.

### 4 Ignition coil: checking, removal and replacement

1 The ignition coil is a sealed unit, designed to give long service. If a weak spark and difficult starting cause its performance to be suspect, it should be tested by a Honda agent or an auto-electrical expert. A faulty coil must be renewed. It is not practicable to effect a repair.

2 To gain access to the coil, the petrol tank must first be removed as described in Chapter 3, Section 3. The battery and its holder will also have to be removed, as described in Chapter 7, Section 3 to gain access to the inside of the frame where the coil is mounted and retained by two nuts. Remove the nuts and carefully pull the coil part way out so that the wires can be disconnected at the snap connectors. Pull the plug cap off the plug, unscrew it from the plug lead and feed the plug lead through the clip and back into the frame above the engine, to allow the ignition coil to pull clear.

3 Reassembly is the reverse of the removal procedure.

### 5 Contact breaker: adjustment

1 The C50 and C70 models use an ignition system commonly referred to as an 'energy transfer' system. The subtle advantage of this system is that the contact breaker adjustment is used to adjust the ignition timing. The resulting maximum contact breaker gap should be between 0.3 mm and 0.4 mm (0.012 in and 0.016 in). If it is outside these limits, the contact breaker assembly should be renewed, since it is worn out. The ignition timing section describes the method of adjustment. If it should be necessary to remove the contact breaker assembly for further attention, or renewal, it will be necessary to withdraw the flywheel generator from the crankshaft, following the procedure described in Chapter 1, Section 7.

2 The C90 model uses a conventional ignition system in which the contact breaker gap is adjusted first and the backplate adjusted to obtain the correct ignition timing.

3 Remove the two screws and the contact breaker cover on the left-hand side of the cylinder head.

4 Rotate the engine until the contact breaker is in its fully open position. Examine the faces of the contacts. If they are pitted or burnt it will be necessary to remove them for further attention, as described in Section 6 of this Chapter.

5 Check the contact breaker gap to see if it is between 0.3 mm and 0.4 mm (0.012 and 0.016 in). To adjust the contact breaker gap, slacken the two screws that hold the contact breaker assembly and using a small screwdriver in the slot provided, ease the assembly to the correct position. Tighten the screws and recheck the gap to ensure that the assembly has not moved.

6 It is always advisable to check the ignition timing, especially if the contact breaker gap has been reset. It will almost certainly require readjustment in this latter case.

7 Ensure that the sealing gasket is either renewed or is in good condition, before refitting the contact breaker cover and screws.

### 6 Contact breaker assembly: removal, renovation and replacement

1 If the contact breaker points are burned, pitted or badly worn, they should be removed for dressing. If it is necessary to remove a substantial amount of material before the faces can be restored, the points should be renewed.


2 To remove the contact breaker assembly, access must be gained as described in the preceding Section. Slacken and remove the nut at the end of the moving contact return spring. Remove the spring and plain washer and detach the spring. Note that an insulating washer is located beneath the spring, to prevent the electrical current from being earthed.

3 Remove the spring clip from the moving contact pivot and the insulating washer. Withdraw the moving contact, which is integral with the fibre rocker arm.


4 Remove the screws that retain the fixed contact plate and withdraw the plate complete with contact.

5 The points should be dressed with an oilstone or fine emery cloth. Keep them absolutely square during the dressing operation, otherwise they will make angular contact when they are replaced and will quickly burn away.


6 Replace the contacts by reversing the dismantling procedure. Take particular care to replace the insulating washers in the correct sequence, otherwise the points will be isolated electrically and the ignition system will not function.




4.2 The ignition coil is mounted inside the frame




6.3 Remove the screw and release the wire to withdraw the contact breaker assembly



7.5 The condenser is mounted on the stator plate



8.2 When the 'F' mark lines up with the crankcase mark, the points should be about to open



9.1 Check the action of the automatic advance/retard mechanism

## 7 Condenser: removal and replacement

1 A condenser is included in the contact breaker circuitry to prevent arcing across the contact breaker points as they separate. It is connected in parallel with the points and if a fault develops, ignition failure will occur.

2 If the engine is difficult to start or if misfiring occurs, it is possible that the condenser has failed. To check, separate the contact breaker points by hand whilst the ignition is switched on. If a spark occurs across the points and they have a blackened or burnt appearance, the condenser can be regarded as unserviceable.

3 It is not possible to check the condenser without the necessary test equipment. It is best to fit a replacement condenser and observe the effect on engine performance, especially in view of its low cost.

4 To remove the condenser on the C90 model, follow the procedure described in Section 4, for removing the ignition coil as the condenser is clamped to the end of this coil. Slacken the clamp and pull the condenser clear.

5 To remove the condenser on the C50 and C70 models, follow the procedure described in Chapter 1, Section 7, for removing the flywheel generator, as the condenser is mounted on the stator plate. Unsolder the wires on the condenser, remove the fixing screw and pull the condenser clear.

6 Reassemble by reversing the dismantling procedure. Take care not to overheat the condenser when resoldering the wires into position as the insulation is very easily damaged by heat.

## 8 Ignition timing: checking and re-setting

1 To check the ignition timing, remove the generator inspection cover or, in the case of the C90 model, the contact breaker cover on the left-hand side of the cylinder head.

2 If the ignition timing is correct, the contact breaker points will be about to separate when the 'F' line scribed on the rotor of the flywheel coincides exactly with an arrow or an indentation or similar scribe mark on the left-hand crankcase or cover.

3 On the C50 and C70 models having the 'energy transfer' system, the ignition timing is varied by adjusting the contact breaker gap. Slacken the screw holding the contact breaker assembly, and using a small screwdriver in the slot provided, ease the assembly to the correct position. Tighten the screw and recheck the ignition timing. Check that the contact breaker gap is between 0.3 mm and 0.4 mm (0.012 in and 0.016 in), renewing the assembly, if outside these limits.

4 On the C90 models, which have a more conventional system, the ignition timing is adjusted by moving the contact breaker backplate. Before checking the ignition timing, always make sure the contact breaker gap is correct first. The backplate holding the complete contact breaker assembly is slotted, to permit a limited range of adjustment. If the two crosshead screws are slackened a little, the plate can be turned until the points commence to separate, and then locked in this position by tightening the screws.

5 After checking the timing, rotate the engine and check again before replacing the covers. The accuracy of the ignition timing is critical in terms of both engine performance and petrol consumption. Even a small error in setting will have a noticeable effect.

## 9 Automatic advance unit: location and checking action

1 Fixed ignition timing is of little advantage as the engine speed increases and provision is made to advance the timing by centrifugal means, using a balance weight assembly located behind the contact breaker assembly or within the rotor of the flywheel magneto generator. A check is not needed unless the action of the unit is in doubt.

2 To check the action of the unit it is first necessary to withdraw the contact breaker assembly complete from the C90

model or withdraw the rotor of the flywheel magneto generator. Refer to Chapter 1.7 for the dismantling procedure.

3 The counterweights of the automatic advance unit should return to their normal position with smooth action when they are spread apart with the fingers and released. A visual inspection will show signs of damage or broken springs.

4 It is unlikely that the automatic advance unit will need to be dismantled, unless replacement parts have to be fitted.

#### 10 Sparking plug: checking and resetting gap

1 A 10 mm NGK sparking plug is fitted to all C50 and C70 models as standard, the grade depending on the model designation. Refer to the Specifications Section heading this Chapter for the recommended grades. The C90 model has a 12 mm plug.

2 All models use a sparking plug with a 12.7 mm reach which should be gapped at 0.024 in. Always use the grade of plug recommended or the exact equivalent in another manufacturer's range.

3 Check the gap at the plug points during every six monthly or 3,000 mile service. To reset the gap, bend the outer electrode to bring it closer to the central electrode and check that a 0.024 inch feeler blade can be inserted. Never bend the central electrode, otherwise the insulator will crack, causing engine damage if particles fall in whilst the engine is running.

4 The condition of the sparking plug electrodes and insulator can be used as a reliable guide to engine operating conditions. See accompanying diagram.

5 Always carry a spare sparking plug of the correct grade. In the rare event of plug failure it will enable the engine to be restarted.

6 Never over-tighten a sparking plug, otherwise there is risk of stripping the threads from the cylinder head, particularly those cast in light alloy. The plug should be sufficiently tight to seat firmly on the copper sealing washer. Use a spanner that is a good fit, otherwise the spanner may slip and break the insulator.

7 Make sure the plug insulating cap is a good fit and free from cracks. This cap contains the suppressor that eliminates radio and TV interference.

#### 11 Fault diagnosis: ignition system

Symptom	Cause	Remedy
Engine will not start	No spark at plug	Try replacement plug if gap correct. Check whether contact breaker points are opening and closing, also whether they are clean. Check whether points arc when separated. If so, renew condenser. Check ignition switch and ignition coil. Battery discharged. Switch off all lights and use emergency start.
Engine starts but runs erratically	Intermittent or weak spark	Try replacement plug. Check whether points are arcing. If so, replace condenser. Check accuracy of ignition timing. Low output from flywheel magneto generator, or imminent breakdown of ignition coil. Check unit for freedom of action and broken springs.
	Automatic advance unit stuck or damaged	




Fig. 6.2. Rear wheel assembly - C90 model

- |                                 |                    |                              |                 |
|---------------------------------|--------------------|------------------------------|-----------------|
| 1 Sprocket                      | 9 Bearing spacer   | 18 Inner tube                | 27 Oil seal     |
| 2 Shock absorber rubber (4 off) | 10 Spoke (18 off)  | 19 Rim tape                  | 28 Bolt         |
| 3 Wheel spindle                 | 11 O-ring          | 20 Brake shoe (2 off)        | 29 Bolt         |
| 4 Stub axle                     | 12 Wheel rim       | 21 Brake shoe spring (2 off) | 30 Nut          |
| 5 Spacer                        | 13 Tyre            | 22 Bolt (4 off)              | 31 Nut (4 off)  |
| 6 Spacer                        | 14 Spokes (18 off) | 23 Spindle nut               | 32 Split pin    |
| 7 Wheel hub                     | 15 Brake backplate | 24 Stub axle nut             | 33 Ball bearing |
| 8 Shock absorber hub            | 16 Operating cam   | 25 Tab washer (2 off)        | 34 Ball bearing |
|                                 | 17 Brake lever arm | 26 Washer (2 off)            | 35 Ball bearing |